INSTALLATION INSTRUCTIONS

Autopilot™ Automated Steering System

Fendt 9xx Vario
Year 2007 and Newer

- 924 Vario
- 927 Vario
- 930 Vario
- 933 Vario
- 936 Vario
- 939 Vario

Version 5.00
Revision A
October 2012
Part number 54035-129-E05

Trimble

Legal Notices

Agriculture Business Area

Trimble Agriculture Division
10355 Westmoor Drive
Suite #100
Westminster, CO 80021
USA
www.trimble.com

Copyright and Trademarks

© 1999–2012, Trimble Navigation Limited. All rights reserved.
Trimble, the Globe & Triangle logo, *Ag*GPS, and FmX are trademarks of Trimble Navigation Limited, registered in the United States and in other countries. Autopilot, AutoSense, and CFX-750 are trademarks of Trimble Navigation Limited. Developed under a License of the European Union and the European Space Agency.

All other trademarks are the property of their respective owners.

Legal Notices

Release Notice

This is the October 2012 release (Revision A) of the Autopilot Automated Steering System Installation Instructions, part number 54035-129-E05. It applies to version 5.00 of the Autopilot automated steering system.

The following limited warranties give you specific legal rights. You may have others, which vary from state/jurisdiction to state/jurisdiction.

Product Limited Warranty

Trimble warrants that this Trimble product and its internal components (the "Product") shall be free from defects in materials and workmanship and will substantially conform to Trimble's applicable published specifications for the Product for a period of one (1) year, starting from the earlier of (i) the date of installation, or (ii) six (6) months from the date of product shipment from Trimble. This warranty applies only to the Product if installed by Trimble or a distributor authorized by Trimble to perform Product installation services.

Software Components and Enhancements

All Product software components (sometimes hereinafter also referred to as "Software") are licensed and not sold. Any Software accompanied by a separate End User License Agreement ("EULA") shall be governed by the terms, conditions, restrictions and limited warranty terms of such EULA notwithstanding the preceding paragraph. During the limited warranty period you will be entitled to receive, at no additional charge, such Fix Updates and Minor Updates to the Product software as Trimble may develop for general release, subject to the procedures for delivery to purchasers of Trimble products generally. If you have purchased the Product from an authorized Trimble distributor rather than from Trimble directly, Trimble may, at its option, forward the software Fix Update or Minor Update to the Trimble distributor for final distribution to you. Major Upgrades, new products, or substantially new software releases, as identified by Trimble are expressly excused from this enhancement process and limited warranty. Receipt of software updates shall not serve to extend the limited warranty period.
For purposes of this warranty the following definitions shall apply: (1) "Fix Update" means an error correction or other update created to fix a previous software version that does not substantially conform to its published specifications; (2) "Minor Update" occurs when enhancements are made to current features in a software program; and (3) "Major Upgrade" occurs when significant new features are added to software, or when a new product containing new features replaces the further development of a current product line. Trimble reserves the right to determine, in its sole discretion, what constitutes a significant new feature and Major Upgrade.

Warranty Remedies

Trimble's sole liability and your exclusive remedy under the warranties set forth above shall be, at Trimble's option, to repair or replace any Product that fails to conform to such warranty ("Nonconforming Product"), and/or issue a cash refund up to the purchase price paid by you for any such Nonconforming Product, excluding costs of installation, upon your return of the Nonconforming Product to Trimble in accordance with Trimble's standard return material authorization process. Such remedy may include reimbursement of the cost of repairs for damage to third-party equipment onto which the Product is installed, if such damage is found to be directly caused by the Product as reasonably determined by Trimble following a root cause analysis.

Warranty Exclusions and Disclaimer

These warranties shall be applied only in the event and to the extent that (i) the Products and Software are properly and correctly installed, configured, interfaced, maintained, stored, and operated in accordance with Trimble's relevant operator's manual and specifications, and; (ii) the Products and Software are not modified or misused. The preceding warranties shall not apply to, and Trimble shall not be responsible for defects or performance problems resulting from (i) the combination or utilization of the Product or Software with hardware or software products, information, data, systems, interfaces or devices not made, supplied or specified by Trimble; (ii) the operation of the Product or Software under any specification other than, or in addition to, Trimble's standard specifications for its products; (iii) the unauthorized, installation, modification, or use of the Product or Software; (iv) damage caused by accident, lightning or other electrical discharge, fresh or salt water immersion or spray; or (v) normal wear and tear on consumable parts (e.g., batteries). Trimble does not warrant or guarantee the results obtained through the use of the Product.

THE WARRANTIES ABOVE STATE TRIMBLE'S ENTIRE LIABILITY, AND YOUR EXCLUSIVE REMEDIES, RELATING TO PERFORMANCE OF THE PRODUCTS AND SOFTWARE. EXCEPT AS OTHERWISE EXPRESSLY PROVIDED HEREIN, THE PRODUCTS, SOFTWARE, AND ACCOMPANYING DOCUMENTATION AND MATERIALS ARE PROVIDED "AS-IS" AND WITHOUT EXPRESS OR IMPLIED WARRANTY OF ANY KIND BY EITHER TRIMBLE NAVIGATION LIMITED OR ANYONE WHO HAS BEEN INVOLVED IN ITS CREATION, PRODUCTION, INSTALLATION, OR DISTRIBUTION INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, TITLE, AND NONINFRINGEMENT. THE STATED EXPRESS WARRANTIES ARE IN LIEU OF ALL OBLIGATIONS OR LIABILITIES ON THE PART OF TRIMBLE ARISING OUT OF, OR IN CONNECTION WITH, ANY PRODUCTS OR SOFTWARE. SOME STATES AND JURISDICTIONS DO NOT ALLOW LIMITATIONS ON DURATION OR THE EXCLUSION OF AN IMPLIED WARRANTY, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

TRIMBLE NAVIGATION LIMITED IS NOT RESPONSIBLE FOR THE OPERATION OR FAILURE OF OPERATION OF GPS SATELLITES OR THE AVAILABILITY OF GPS SATELLITE SIGNALS.

Limitation of Liability

TRIMBLE'S ENTIRE LIABILITY UNDER ANY PROVISION HEREIN SHALL BE LIMITED TO THE AMOUNT PAID BY YOU FOR THE PRODUCT OR SOFTWARE LICENSE. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL TRIMBLE OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES WHATSOEVER UNDER ANY CIRCUMSTANCE OR LEGAL THEORY RELATING IN ANY WAY TO THE PRODUCTS, SOFTWARE AND ACCOMPANYING DOCUMENTATION AND MATERIALS, (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION, OR ANY OTHER PECUNIARY LOSS), REGARDLESS WHETHER TRIMBLE HAS BEEN ADVISED OF THE POSSIBILITY OF ANY SUCH LOSS AND REGARDLESS OF THE COURSE OF DEALING WHICH DEVELOPS OR HAS DEVELOPED BETWEEN YOU AND TRIMBLE. BECAUSE SOME STATES AND JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

NOTE: THE ABOVE LIMITED WARRANTY PROVISIONS MAY NOT APPLY TO PRODUCTS OR SOFTWARE PURCHASED IN THE EUROPEAN UNION. PLEASE CONTACT YOUR TRIMBLE DEALER FOR APPLICABLE WARRANTY INFORMATION.

Notices

Class B Statement – Notice to Users. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and the receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help.
Changes and modifications not expressly approved by the manufacturer or registrant of this equipment can void your authority to operate this equipment under Federal Communications Commission rules.

Notice to Our European Union Customers

For product recycling instructions and more information, please go to:
www.trimble.com/ev.shtml



Recycling in Europe: To recycle Trimble WEEE, Call +31 497 53 2430, and ask for the "WEEE Associate"
Or
Mail a request for recycling instructions to:
Trimble Europe BV
c/o Menlo Worldwide Logistics
Meerheide 45
5521 DZ Eersel, NL

Safety Information

Always follow the instructions that accompany a Warning or Caution. The information they provide is intended to minimize the risk of personal injury and/or damage to property. In particular, observe safety instructions that are presented in the following format:

WARNING – This alert warns of a potential hazard, which, if not avoided, can cause severe injury.

CAUTION – This alert warns of a hazard or unsafe practice which, if not avoided, can cause injury or damage.

Note – *An absence of specific alerts does not mean that there are no safety risks involved.*

Warnings

WARNING – When you are working on the vehicle's hydraulic systems, vehicle attachments that are suspended can drop. If you are working around the vehicle, you could suffer serious injury if an attachment dropped on you. To avoid this risk, lower all vehicle attachments to the ground before you begin work.

WARNING – If someone else attempts to drive the vehicle while you are working on or under it, you can suffer serious or fatal injuries. To avoid this possibility, install a lockout box on the battery terminal to prevent the battery from being reconnected, remove the key from the vehicle's ignition switch, and attach a "Do not operate" tag in the cab.

WARNING – Agricultural chemicals can pose serious health risks. If the vehicle has been used to apply agricultural chemicals, steam clean the vehicle to remove any chemical residue from the areas of the vehicle where you will be working.

WARNING – Vehicle cabs can be quite high in the air. To avoid potentially serious injury through falling from this height, always use the steps and handrails, and face the vehicle, when you enter or exit it.

Cautions

CAUTION – When the vehicle has been running, parts of the vehicle, including the engine and exhaust, can become extremely hot and can cause serious burns. To avoid burns, allow hot machine parts to cool before you begin working on them.

CAUTION – The system installation may bring you into contact with chemical substances, such as oil, which can cause poisoning. Wash your hands thoroughly after you finish working on the system.

CAUTION – Battery posts, terminals, and related accessories contain lead and lead compounds, which can cause serious illness. To avoid ingesting lead, wash your hands thoroughly after touching the battery.

CAUTION – Always wear protective equipment appropriate to the job conditions and the nature of the vehicle. This includes wearing protective glasses when you use pressurized air or water, and correct protective welder's clothing when welding. Avoid wearing loose clothing or jewelry that can catch on machine parts or tools.

CAUTION – Parts of the vehicle may be under pressure. To avoid injury from pressurized parts, relieve all pressure in oil, air, and water systems before you disconnect any lines, fittings, or related items. To avoid being sprayed by pressurized liquids, hold a rag over fill caps, breathers, or hose connections when you remove them. Do not use your bare hands to check for hydraulic leaks. Use a board or cardboard instead.

CAUTION – Do not direct pressurized water at:
- electronic or electrical components or connectors
- bearings
- hydraulic seals
- fuel injection pumps
- any other sensitive parts or components



Set the hose pressure as low as practicable, and spray at a 45° to 90° angle. Keep the nozzle of the power washer away from the machine at the distance recommended by the manufacturer.

CAUTION – To prevent damage to the system, make sure that no wires or hoses interfere with or catch on any mechanical linkages, or contact any machine parts that get hot.

Contents

Legal Notices 2

Safety Information 3

Warnings 3

Cautions 4

1 Introduction 3

Technical assistance 3

Manual system upgrade to Autopilot 4

CFX-750 display and FmX integrated display 4

Required components 4

Antenna mounting kits 4

Autopilot hardware organization: As shipped 5

Preparing the vehicle for installation 6

2 Hydraulic Control Valve Installation 7

Hydraulic control valve components 8

Prepare the Autopilot manifold and the DCVB 9

Checking the hydraulics 18

3 Autosense Steering Device Installation 19

Autosense steering device components 20

Installing the Autosense device 21

Preparing the harness: P/N 54602 Rev C 23

4 Antenna/Receiver Installation 25

Antenna and receiver installation options 26

Possible mounting methods 26

Attaching the plate with VHB adhesive 27

AG-372 receiver with AgGPS 450/900 radio module (if equipped) components 29

Installing the AG-372 GPS receiver with AgGPS 450/900 radio module (if equipped) 30

Removable installation 30

Permanent installation 30

Installing an AG-372 receiver with magnetic feet 35

AgGPS 542 receiver components 37

Installing the AgGPS 542receiver 38

5 Display Installation 41

FmX integrated display components 42

CFX-750 display components 43

Preparing the FmX integrated display 44

Installing the FmX integrated display 45

FmX integrated display: Installing the wiring harness 46

Preparing the CFX-750 display 47

Installing the CFX-750 display 48

CFX-750 display: Installing the wiring harness 49

FmX integrated display and CFX-750 display: Connecting accessory options 50

AgCam 50

CFX-750 and FmX displays: Installing the GNSS antenna and plate 52

VHB adhesive attachment 52

CFX-750 and FmX displays: Installing the RTK radio antenna 56

6 Power Harness Installation 57
FmX integrated display components 58
CFX-750 display components 59
Installing the power harness for the display 61
Configuring the power bus options for the display 63
Display power button is used to turn on the Autopilot system 63
External switch is used to turn on the Autopilot system 64
Installing the optional illuminated full or standard Euro switch 64
Ignition is used to turn on the Autopilot system 65

7 Remote Engage Switch Installation 67
Remote engage switch components: Rocker switch 68
Remote engage switch components: Foot switch 69
Preparing the remote engage cable 70
Using the remote engage switch 73

8 Controller Installation 74
Installing the controller 75
Controller connections 77

9 Final Machine Check 80

CHAPTER 1

Introduction

In this chapter:

- Technical assistance
- Manual system upgrade to Autopilot
- Required components
- Autopilot hardware organization: As shipped
- Preparing the vehicle for installation

This manual describes how to install the Trimble® Autopilot™ automated steering system.

Even if you have used another GNSS (Global Navigation Satellite System), such as the United States' GPS (Global Positioning System), before, spend some time reading this manual to learn about the special features of this product. If you are not familiar with GNSS, go to the Trimble website (www.trimble.com) for an interactive look at Trimble and GNSS.

Technical assistance

If you have a problem and cannot find the information you need in the product documentation, contact Trimble technical support:

1. Go to the Trimble website (www.trimble.com).
2. Click the Support & Training link at the top of the screen, select Support and then select Support A–Z list of products.
3. Scroll to the bottom of the list.
4. Click the submit an inquiry link. A form appears.
5. Complete the form and then click Send.

Manual system upgrade to Autopilot

CFX-750 display and FmX integrated display

Retain	Remove
CFX-750™ display: P/N 94000-xx	
Power cable CFX-750 display: P/N 77282	
FmX® integrated display: P/N 93100-xx	
Power cable FmX display: P/N 66694	
Antenna for display: P/N 60600-02 (DGPS) or 77038-00 (OmniStar/RTK)	
Antenna to receiver cable: P/N 50449	
Basic cable (both displays): P/N 67258	

Required components

Kits required	Special tools
Platform kit: P/N 54035-129	Drill
Hydraulic hose kit: P/N 88562	5/16'' drill bit
	3/8-16 tap
	2" hole saw

Antenna mounting kits

Kits required
Antenna V plate mount and AG-372 receiver magnetic mount: P/N 62388-01 (includes magnets for quick release of the AG-372 receiver – see Chapter 4, Antenna/Receiver Installation).

Autopilot hardware organization: As shipped

Hardware	Component	See...
Platform kit: P/N 54035-129	Hydraulic valve	Chapter 2
	Hydraulic manifold	
	Transducer flow switch	
	Manual override cable	
	Hydraulic brackets and bolt kits	
	Hydraulic valve cable	
	Autosense™ steering device and cabling	Chapter 3
	Autosense mounting bracket and hardware	
	Power switch	Chapter 6
	Bolt kit controller	Chapter 8
Hydraulic hose kit: P/N 88562	Hydraulic hoses	Chapter 2
	Hydraulic adaptors	
Roof bracket kit: (P/N 53676)	Roof brackets	Chapter 4
	Bolt kit, roof bracket	
GNSS receiver	GNSS receiver	Chapter 4
	GNSS antenna	
	GNSS receiver power/data cable	
	RTK radio, cable, and radio antenna	
Display	CFX-750 display	Chapter 5
	FmX integrated display	
	Display cable	
	Mounting bracket	
Common parts	Controller	Chapter 8
	Controller mounting bracket	
	Cable kit: Main wiring harness Power bus auxiliary wiring harness Sonalert alarm	

Preparing the vehicle for installation

Note – *The left and right sides of the vehicle are referenced while standing behind the unit, facing the normal direction of travel.*

1. Park the vehicle on a hard, level surface. Block the front and rear wheels.
2. Align the steering straight ahead. On an articulated vehicle, install the articulation locks.
3. Remove all dirt and debris from the areas of the vehicle where the Autopilot system will be installed.
4. Open all kit boxes and check the contents of the box against the packing list/s. Lay all of the parts out on a clean workbench.

CHAPTER 2


Hydraulic Control Valve Installation

In this chapter:

- Hydraulic control valve components
- Prepare the Autopilot manifold and the DCVB
- Checking the hydraulics

This chapter describes how to install the hydraulic control valve and hoses.

Hydraulic control valve components




	Description	P/N
1	Fitting (2)	GE08L7/16UNFOMD
2	Fitting (8)	GEI5L3/4UNFOMD
3	Fitting (3)	EL15LOMD
4	Fitting	EL18LOMD
5	Fitting	EWI5LOMD
6	Fitting (2)	GRI8/15LOMD
7	Fitting (3)	RED18/15LOMD
8	Fitting	4 HP50N

	Description	P/N
20	60” hose (2)	F451TCC3C5-15L-15L-08-6011 (1520 mm)
21	85” hose (2)	F451TCC3C5-15L-15L-08-8511 (2150 mm
22	87” hose (2)	F451TCC3C4-15L-15L-08-8711 (2200 mm)
23	93” hose	F451TCC3C5-15L-15L-08-9311 (2350 mm)
24	87” hose	F451TCC3C4-15L-15L-08-87 (2200 mm)
25	91” hose	F451TCC3C4-08L-08L-04-91 (2300 mm)
26	75” hose	F451TCDOC4-08L-08L-04-75 (1900 mm)

Prepare the Autopilot manifold and the DCVB


Step 1

Insert the provided 15L fitting into the P port of the Autopilot manifold.



Step 2

Insert the two provided 15L fittings into the A and B ports of the Autopilot manifold.




Step 3

Insert the provided 15L fitting into the T port of the Autopilot manifold ❶.


Insert the two provided 8L fittings into the LS1 and LS2 ports of the Autopilot manifold ❷.

Remove the plug and then insert the provided PTS cartridge into the PTS port of the Autopilot manifold ❸.



Step 4

Insert the provided 15L straight fittings into the V1 and V2 ports and the C1 and C2 ports of the DCBV.



Step 5


Insert the provided 15L run tee fittings onto the C1 and C2 ports of the DCBV manifold. Orient them with the branch facing the base of the DCBV.



Step 6

The Autopilot manifold and DCBV will be installed at the rear of the machine, above the hydraulic remote stack.


Use the manifolds as a template to mark the required mounting holes.



Step 7

On the Autopilot manifold, align the holes so that the manifold is attached to the steel support bracket under the top sheetmetal cover.


Use spacers in between the sheetmetal cover and the bracket to ensure a tight bolted connection.



Step 8

Drill 7/16" holes ❶ for mounting the Autopilot manifold.


Drill 5/16" holes ❷ for mounting the DCBV.



Step 9


Attach the DCBV to the machine using 1/4" bolts washers and nuts.

Mount the DCBV in the location shown.



Step 10

Attach the Autopilot manifold to the machine using 3/8" bolts washers and nuts.



Step 11


The hydraulic connections on the machine are just in front of the right rear wheel of the machine. For easier access, remove this wheel.



Step 12


Carefully label the hoses.

- P (15L line behind A next to T) ❶
- LS (8L line behind B) ❷



Step 13

Remove the labeled hoses from the machine.




Step 14

Attach the provided 18L run tee fitting to the P port.

Reconnect the existing P line to the end of the run tee.

Connect the 18L-15L reducer to the branch of the run tee fitting and then connect the 90° end of the P hose to the reducer.

Route the other end of the hose to the P port on the Autopilot manifold



Step 15

Attach the 15L run tee fitting to the T port on the machine. Connect the existing machine T line to the end of the run tee fitting.


Connect the swivel 90° 15L fitting to the branch of the tee fitting.

Connect the straight end of the T hose to the swivel 90° fitting and then route the hose to the Autopilot T port.



Step 16

Attach the LS1 hose to the line on the machine going to the orbital hand pump.



Attach the LS2 line to the line on the machine going to the machine hydraulic pump or priority valve.



Step 17

Attach the provide 18l-15L reducer fitting to the A and B ports on the machine.

Connect the C2 hose to the B port and the C1 hose to the A port.

Route the C1 and C2 hoses to the C1 and C2 ports of the DCBV





Step 18

Attach the provide 18l-15L Union fitting to the A ❶ and B ❷ hydraulic hose lines on the machine.

Connect the V1 hose to the A hose and the V2 hose to the B hose.


Route the V1 and V2 hoses to the V1 and V2 ports of the DCBV.





Step 19

Connect the P hose to the P port of the autopilot manifold.



Step 20

Connect the LS1 and LS2 lines to the LS1 and LS2 ports of the Autopilot manifold.


Connect the T line to the T port of the Autopilot manifold.



Step 21

Connect the 90° ends of the A and B hoses to the A and B ports of the Autopilot manifold.


Route the other ends of the hoses to the C1 and C2 ports of the DCBV.



Step 22

Connect the V1 hose to the V1port of the DCBV.


Connect the V2 hose to the V2port of the DCBV.



Step 23

Connect the A line from the Autopilot manifold to the branch of the run tee fitting on the C1 port of the DCBV.

Connect the B line from the Autopilot manifold to the branch of the run tee fitting on the C2 port of the DCBV.



Step 24


Connect the C1 hose to the end of the tee fitting on the C1 port of the DCBV.

Connect the C2 hose to the end of the tee fitting on the C2 port of the DCBV.



Step 25

Install the manual override pressure transducer into the DCBV.



Checking the hydraulics

1. Make sure that all the hydraulic connections are tight.
2. Check the oil level in the hydraulic tank. If necessary, top it up.
3. Check for hydraulic leaks. Connect the battery and then start the machine. Once you complete the leak check, disconnect the battery.

CHAPTER 3

Autosense Steering Device Installation

In this chapter:

- Autosense steering device components
- Installing the Autosense device
- Preparing the harness: P/N 54602 Rev C


This chapter describes how to install the Autosense™ steering device. If the required mounting location is not accessible, chose a different place. To ensure proper function, the Autosense device must be located where it is free of obstructions and can rotate with the wheels when they turn.

On articulated vehicles, mount the Autosense device on the opposite side of the pivot point to the Autopilot controller.

Mount the device base down or base up so that it maintains a level orientation. Do not mount it on its side. An angle of up to 10° in any direction is acceptable.

To avoid stretching the cable, leave adequate length on the service loop.

Autosense steering device components



Item	Description	P/N
❶	P-6 connector	
❷	Power connector	
❸	Autosense connector	
❹	Jumper cable	57560
❺	Autosense steering cable	57885

Installing the Autosense device

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information.

Step 1

Attach the Autosense sensor to the sensor mounting bracket with the provided screws.



Step 2


The sensor will be installed on the right front wheel in the location shown.

Remove the two bolts and then re-use them to attach the Autosense mounting plate to the machine.



Step 3

Connect the Autosense cabling to the Autosense sensor.



Step 4

Route the Autosense cabling to the NavController II.


Be sure it does not contact any moving components and is not punched or pulled as the wheels are steered from full right to left.



Step 5

Plug the steering sensor cable to P-6 on the Autopilot controller main wiring harness.


The P6 connector is labeled **Steering Sensor**.



Preparing the harness: P/N 54602 Rev C


Step 1

Remove the black Deutsch DTM receptacle from the P-13 sensors leg of the auxiliary harness. See Chapter 8, Controller Installation.




Step 2

Remove the plug from cavity number 1.




Step 3

Remove the wedge from the connector.



Step 4

Insert the DTM pin labeled “Cavity 1” into the connector.




Step 5

Pull back on the wire to seat the pin. Replace the wedge in the connector.

Step 6

Plug the assembled Deutsch receptacle into the P-13 sensors leg of the AutoPilot controller auxiliary harness. See Chapter 8, Controller Installation.



CHAPTER 4

Antenna/Receiver Installation

In this chapter:

- Antenna and receiver installation options
- AG-372 receiver with AgGPS 450/900 radio module (if equipped) components
- Installing the AG-372 GPS receiver with AgGPS 450/900 radio module (if equipped)
- Installing an AG-372 receiver with magnetic feet
- AgGPS 542 receiver components
- Installing the AgGPS 542receiver

This chapter describes how to install the required receiver and antenna, and radio module (if used).

To install the antenna for CFX-750 or FmX display, see Chapter 5, Display Installation.

Antenna and receiver installation options

There are two options for mounting components (the antenna, radio module, or GNSS receiver), on the cab roof depending on the accuracy required and the antenna type:


- **VHB mount** – Attach a 4" x 6" plate or a V plate directly to the roof with VHB (Very High Bond) adhesive for magnetic mounting. See page 27.
- **Magnetic mounting** – Magnetic mounting for quick release from the 4" x 6" plate or the V plate.

Possible mounting methods

GNSS receiver	VHB mounted plate	VHB V mounted plate
FmX integrated display; CFX-750 display	✓	✓
AG-372 receiver	✘	✓
AgGPS 542 receiver	✓	✓

Notes:

- *For quick release magnetic mounting with an* AG-372 *receiver, order the kit listed in Antenna mounting kits, page 4.*
- *For WAAS, EGNOS, OmniSTAR VBS, Beacon, and DGPS applications, place either of the plates in a firm location using the VHB.*



Magnetic mount on the V plate

Attaching the plate with VHB adhesive

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information.

Standard 4" x 6" plates are provided in most kits. You can use the VHB mounting method to attach either a 4" x 6" plate or a V plate.

- **RTK, OmniSTAR, DGPS, GLONASS applications** – To use this method for high accuracy, the surface must be rigid and free of “oil panning”. The V plate provides repeatable positioning of the antenna.
- **WAAS, EGNOS, OmniSTAR VBS, Beacon applications** – Use a 4" x 6" plate for simplified installation in applications where high accuracy is not critical.

Step 1


Clean the antenna location on the roof of the cab with a light solvent to remove oil and dust. Apply force to the roof to find a firm location.




Step 2

Remove the backing from the other side of the VHB strips and then apply the plate to the cab roof. The narrow end of the plate points forward. Ensure that the VHB strips make even contact with the surface. Apply pressure and then leave for approximately 30 minutes to adhere.

Note – *The arrow points to the front of the vehicle.*




V plate



4" x 6" plate

AG-372 receiver with *Ag*GPS 450/900 radio module (if equipped) components



Item	Description	Trimble part number
❶	*Ag*GPS 450 or 900 radio (if equipped)	
❷	Radio antenna cable and magnetic mount	
❸	*Ag*GPS 450 or 900 radio antenna	
❹	Antenna/receiver cable	54608
❺	*Ag*GPS Autopilot controller	


Installing the AG-372 GPS receiver with AgGPS 450/900 radio module (if equipped)

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information.

For a removable installation to attach the AG-372 receiver plate to the cab roof, use VHB to attach the V plate to the roof, and then stick the receiver plate to the V plate with magnets.

Removable installation

Attach the three provided magnets to the plate with the ¼" flathead screws and hardware provided.



Underside of plate

Permanent installation


Step 1

Remove the blanking plate and set it aside.




Step 2

Place the integrated radio inside the AG-372 receiver. Ensure that the circuit board is aligned with the slot in the vertical wall of the receiver.




Step 3

Slide the integrated radio back so that it is flush with the vertical wall of the receiver.



Step 4


Use a #1 or #2 Phillips screwdriver and the supplied screws to install the integrated radio. First insert and tighten the two screws on the horizontal wall (arrowed), and then insert the remaining screws.



Step 5

Install the supplied antenna cable.

Notes: *The housing can accommodate a cable diameter of up to ¼".*




Step 6

Route the cable through the cable channel and then insert the cable cover.




This image shows the unit with the cable routed through the channel.




Step 7

Attach the antenna base to the rear of the plate with the two flathead screws provided.



Step 8

Attach the radio antenna to the antenna base.



Step 9

Position the AG-372 receiver and radio on the mounting plate with the connector ports facing the radio antenna. Align the three bolt holes with the receiver, radio, and mounting plate.




Step 10

Insert the nylon bushings provided.



Step 11


Insert the bolts through the receiver, radio, and mounting bracket. Place nuts on the bolt ends and then tighten them.



Step 12

Magnet method


Place the receiver on the roof by aligning the magnets with the V plate. Ensure that the handle ❶ is toward the back of the vehicle.



Step 13

Connect the cable from the cab controller into port A ❶ of the AG-372 receiver. Bolt the cable clamp ❷ to the left side of the receiver.

Route the cable into the cab and into the controller.



Installing an AG-372 receiver with magnetic feet

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information.

Use this option only when all other options are unavailable. It requires a firm surface for mounting to avoid vertical vibration and is not an easily repeatable location when moving receivers. Many cabs do not offer roof bolts; you may need to drill or to construct a firm location.

Step 1


Attach the magnets to the receiver mounting plate. Mount the AG-372 receiver using the three ¼" bolts.

Place the nuts on the receiver side.



Step 2

Turn the mounting plate upside down. Stick the covers onto the magnets as shown.




Step 3

Clean the antenna location on the roof of the cab with a light solvent to remove oil and dust.


Remove the backing from the VHB strips and then apply the plates to the cab roof.

Attach the three mounting plates so that the receiver is as firm as possible.




Step 4

Stick the antenna magnetic mounts at the center of the mounting plates.




Step 5

Connect the antenna cable to port A of the GPS receiver and then route the cable toward the NavController II harness.



*Ag*GPS 542 receiver components



Item	Description	Trimble part number
❶	Radio antenna magnetic base	
❷	Radio antenna	
❸	Radio antenna cable	
❹	*Ag*GPS 542 GPS receiver	
❺	Antenna cable	
❻	Receiver cable	62037
❼	To controller “P3 GPS”	
❽	Antenna magnetic mount	
❾	*Ag*GPS 542 antenna	

Installing the AgGPS 542receiver


WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information.

Step 1

Attach the large magnet with a $^{5}/_{8}$" stud to the GPS antenna.



If the antenna has magnets built in, skip this step.



Step 2

GLONASS,RTK, OmniSTAR, DGPS applications

For repeatable positioning, place the antenna against the lip at the narrow end of the V plate.



Step 3

Attach the antenna/receiver cable to the antenna and then route the cable into the cab through the rubber grommet at the base of the rear window. Secure the cable along the way.



Step 4

Mount the receiver in a convenient location in the cab. Route the antenna cable to the receiver and then connect it.




Step 5

Identify the correct adaptor for the radio connection:

❶ Reverse polarity TNC-to-N for 900 MHz radios

❷ Normal polarity TNC-to-N for 400 MHz radios



Step 6

Attach the adaptor to the radio port.




Step 7

Connect the radio antenna cable to the radio port adaptor.



Step 8

Connect the controller cable to the 26-pin connector of the receiver. Controller cable connections will be completed in Chapter 8, Controller Installation.



Step 9

Connect the radio antenna to the magnetic antenna base.



Step 10

Attach the magnetic radio antenna base to the rear of the V plate on the roof. If the cable does not reach the V plate, use the 4" x 6" plate with the VHB provided to relocate the antenna.



CHAPTER 5


Display Installation

In this chapter:

- FmX integrated display components
- CFX-750 display components
- Preparing the FmX integrated display
- Installing the FmX integrated display
- Preparing the CFX-750 display
- Installing the CFX-750 display
- CFX-750 display: Installing the wiring harness
- FmX integrated display and CFX-750 display: Connecting accessory options
- CFX-750 and FmX displays: Installing the GNSS antenna and plate
- CFX-750 and FmX displays: Installing the RTK radio antenna

This chapter describes how to install and connect the FmX integrated display or the CFX-750 display in the vehicle.


FmX integrated display components



⚠ **CAUTION –** Connecting the Port Replicator on the FmX to NavController II cable ❺ to the P4 or P12 connector of the NavController II harness ⓬ will result in damage to the FmX / FM-1000 integrated display, and will void the warranty.

Item	Description	Trimble part number
❶	FmX integrated display	93100-02
❷	FmX power cable	66694
❸	FmX power cable with relay and switch (power bus)	67259
❹	Basic power cable	67258
❺	FmX to NavController II cable with port replicator	75741
❻	2 pin DTM to 2 pin DT power adaptor	67095
❼	NavController II	55563-00
❽	8 m GNSS TNC/TNC RT angle cable	50449
❾	AG25 GNSS antenna	77038-00
❿	NMO to TNC 20ft antenna cable and base	72122
⓫	900 MHz radio antenna kit	22882-10
⓬	Main NavController II cable	54601

CFX-750 display components



CAUTION – Connecting the Port Replicator on the FmX to NavController II cable ❺ to the P4 or P12 connector of the NavController II harness ⓬ will result in damage to the FmX / FM-1000 integrated display, and will void the warranty.

Item	Description	Trimble part number
❶	CFX-750 display ***Note –*** *RTK password required.*	93100-02
❷	CFX-750 power cable	66694
❸	CFX-750 power cable with relay and switch (power bus)	67259
❹	Basic power cable	67258
❺	FmX to NavController II cable with port replicator	75741
❻	2 pin DTM to 2 pin DT power adaptor	67095
❼	NavController II	55563-00
❽	8 m GNSS TNC/TNC RT angle cable	50449
❾	AG25 GNSS antenna	77038-00
❿	NMO to TNC 20ft antenna cable and base	72122
⓫	900 MHz radio antenna kit	22882-10
⓬	Main NavController II cable	54601

Preparing the FmX integrated display

Step 1

Locate the FmX integrated display, the RAM mount, and the RAM mount clamp.



Step 2

Use the provided metric hardware to attach the RAM mount to the rear of the display.



Step 3

Attach the RAM mount to the rear of the display.



Installing the FmX integrated display

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information.


Step 1

Decide where you will mount the display in the vehicle cab and then use the provided bolts to attach the bar mount to the rail. Attach the free end of the RAM mount to the bar mount and then tighten the clamp on the RAM mount so that the display is secure.

Step 2

Connect the cable to the C port of the FmX integrated display.


To connect power to the FmX integrated display, see Chapter 6, Power Harness Installation.



FmX integrated display: Installing the wiring harness


Step 1

Locate the cable that connects the FmX integrated display to the NavController II ❶.



Step 2

Connect the cable to the P3 connector on the NavController II main harness, and then route the cable from the NavController II to the mounting location on the FmX integrated display.



Preparing the CFX-750 display

Step 1

Locate the CFX-750 display, the RAM mount, and the RAM mount clamp.



Step 2

Use the provided metric hardware to attach the RAM mount to the rear of the display.



Step 3

Attach the RAM mount to the rear of the display.



Installing the CFX-750 display

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information.

Step 1

Decide where you will mount the display in the vehicle cab and then use the provided bolts to attach the bar mount to the rail.

Attach the free end of the RAM mount to the bar mount and then tighten the clamp on the RAM mount so that the display is secure.

Step 2

Connect the cable to the B port of the CFX-750 display.

To connect power to the CFX-750 display, see Chapter 6, Power Harness Installation.



CFX-750 display: Installing the wiring harness

Step 1

Locate the cable that connects the CFX-750 display to the NavController II.

Step 2

Connect the cable to the P3 connector on the NavController II main harness and then route the cable from the NavController II to the mounting location on the CFX-750 display.



FmX integrated display and CFX-750 display: Connecting accessory options

Note – *Unless otherwise stated, "the display" applies to FmX integrated display or the CFX-750 display.*

AgCam

The AgCam and AgCam cable are accessory items that you can purchase separately from the display. The FmX integrated display allows for up to four video inputs; the CFX-750 display allows up to two.

Step 1

Locate the AgCam and AgCam cable.

Step 2

Mount the AgCam in a secure location and then route the cable towards the display.



FmX display



CFX-750 display


Step 3

Connect the AgCam cable to the display adaptor cable.



Step 4

Connect the display to AgCam adaptor cable to one of the open 12 pin connectors on the back of the display.



CFX-750 and FmX displays: Installing the GNSS antenna and plate

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information.

Note – *The V plate antenna bracket is available on the Autopilot price list. See* *Antenna mounting kits, page 4**.*

VHB adhesive attachment

Standard 4" x 6" plates are provided in most kits. You can use Very High Bond (VHB) to attach either a 4" x 6" plate or a V plate.

- **GLONASS, RTK, OmniSTAR, DGPS applications** – To use this method for high accuracy, the surface must be rigid and free of “oil panning”. The V plate provides repeatable positioning of the antenna.
- **WAAS, EGNOS, OmniSTAR VBS, Beacon applications** – Use a 4" x 6" plate for simplified installation in applications where high accuracy is not critical.

Step 1

Clean the antenna location on the roof of the cab with a light solvent to remove oil and dust.




Step 2

V plate only

Remove the backing from one side of the VHB strips provided and then apply the strips to the plate.


Note – *The VHB strips are pre-applied to the 4" x 6" plate.*




Step 3

Remove the backing from the other side of the VHB strips and then apply the plate to the cab roof. The narrow end points forward. Ensure that the VHB strips make even contact with the surface. Apply pressure and then leave for approximately 30 minutes to adhere.

Note – *The arrow in this figure points to the front of the vehicle.*




V plate



4" x 6" plate

Step 4

If the antenna has magnets built in, omit this step.



Otherwise, attach the large magnet with a $^{5}/_{8}$" stud to the GNSS antenna.



Step 5

GLONASS, RTK, OmniSTAR, DGPS, applications

For repeatable positioning, place the antenna against the lip at the narrow end of the V plate.



WAAS, EGNOS, VBS, Beacon applications

Attach the antenna to the center of the 4" x 6" plate.



Step 6

Both models

Attach the antenna/receiver cable to the antenna and then route the cable into the cab through the rubber grommet at the base of the rear window. Secure the cable along the way.



CFX-750 and FmX displays: Installing the RTK radio antenna

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information.

Step 1

Connect the radio antenna to the magnetic antenna base



Step 2

Attach the magnetic radio antenna base to the rear of the V plate on the roof. If the cable does not reach the V plate, use the 4" x 6" plate with the VHB provided to relocate the antenna.



Step 3

Route cable from the vehicle roof into the cab, and connect the radio cable to the display.

CHAPTER 6


Power Harness Installation

In this chapter:

- FmX integrated display components
- FmX integrated display components
- CFX-750 display components
- Installing the power harness for the display
- Configuring the power bus options for the display

This chapter describes how to install the power harness in the vehicle.


FmX integrated display components



⚠ **CAUTION –** Connecting the Port Replicator on the FmX to NavController II cable ❺ to the P4 or P12 connector of the NavController II harness ⓬ will result in damage to the FmX / FM-1000 integrated display, and will void the warranty.

Item	Description	Trimble part number
❶	FmX integrated display	93100-02
❷	FmX power cable	66694
❸	FmX power cable with relay and switch (power bus)	67259
❹	Basic power cable	67258
❺	FmX to NavController II cable with port replicator	75741
❻	2 pin DTM to 2 pin DT power adaptor	67095
❼	NavController II	55563-00
❽	8 m GNSS TNC/TNC RT angle cable	50449
❾	AG25 GNSS antenna	77038-00
❿	NMO to TNC 20ft antenna cable and base	72122
⓫	900 MHz radio antenna kit	22882-10
⓬	External switch cable included with kit	Part of P/N 67259
⓭	Switch	67095
⓮	NavController II harness	54601

CFX-750 display components



⚠ **CAUTION –** Connecting the Port Replicator on the FmX to NavController II cable ❺ to the P4 or P12 connector of the NavController II harness ⓬ will result in damage to the FmX / FM-1000 integrated display, and will void the warranty.

Item	Description	Trimble part number
❶	CFX-750 display ***Note –*** *RTK password required.*	93100-02
❷	CFX-750 power cable	66694
❸	CFX-750 power cable with relay and switch (power bus)	67259
❹	Basic power cable	67258
❺	FmX to NavController II cable with port replicator	75741
❻	2 pin DTM to 2 pin DT power adaptor	67095
❼	NavController II	55563-00
❽	8 m GNSS TNC/TNC RT angle cable	50449
❾	AG25 GNSS antenna	77038-00


Item	Description	Trimble part number
⑩	NMO to TNC 20ft antenna cable and base	72122
⑪	900 MHz radio antenna kit	22882-10
⑫	External switch cable included with kit	Part of P/N 67259
⑬	External switch included with kit	Part of P/N 67259
⑭	Main NavController II cable	54601

Installing the power harness for the display


WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information.

Step 1

Connect the basic power cable to the vehicle battery and then route the cable into the cab.




CAUTION – If the vehicle has a master electrical disconnect, make sure that the basic power cable (P/N 67258), is not directly attached to the battery terminal that is disconnected by the master switch - the negative pole in this example.
Attach this terminal side just past the main disconnect so that it is as close as possible to the battery but still gets disconnected.
Failure to do so can result in damage to the display.




Step 2

Locate and connect the 4-pin Deutsch DTP receptacle on the power bus ❶ to the 4-pin Deutsch DTP plug ❷ on the basic power cable and then remove the protective cap from the 4-pin Deutsch DTP plug ❸ on the power bus and connect the plug to the 4-pin Deutsch DTP receptacle ❹ on the display power adaptor.



Step 3

Route the display power adaptor to the display mounting location and then connect it to the display.



FmX display



CFX-750 display

Configuring the power bus options for the display


WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information.

When you use the power bus cable, use one of the following configuration methods to turn on the Autopilot system:

- Display power button is used to turn on the Autopilot system
- External switch is used to turn on the Autopilot system
- Ignition is used to turn on the Autopilot system

Display power button is used to turn on the Autopilot system

Connect the 2 pin connectors labeled R2 and P2 on the power bus.




External switch is used to turn on the Autopilot system

Step 1

Connect the cable labeled R7 switch ❶ (included with the power bus) to connector labeled P2 on the power bus ❷ and then route the cable labeled R7 to a switch location.


Note – *To install the switch provided, drill a ¾" hole.*



Step 2

Connect the cable labeled R7 to the switch pins.

Note – *Polarity is not important.*




Installing the optional illuminated full or standard Euro switch

Step 1

Find an available knockout location on the vehicle console.

Note – *An alternative location is required for the switch provided.*




Step 2

Route the cable labeled R7 to the switch location and then connect the cable to the illuminated switch.

Connect the wire labelled S1 to pin 5 on the switch and then connect the wire labelled S2 to pin 4 on the switch.


Note – *Polarity **is** important.*



Step 3

Connect a separate wire to pin 3 on the switch using a spade connector. Route the wire and then connect it to the vehicle switched power.

Note – *This additional wire is required to allow the switch to illuminate.*




Ignition is used to turn on the Autopilot system

Note – *For more information on how to use the ignition sensing option, see the FmX Integrated Display User Guide.*


Step 1

Connect the 2-pin connectors labeled R2 and P2 on the power bus.



Step 2

Connect the cable labeled R8 Ignition (included with the power bus) to connector P3 Ignition on the power bus.




Step 3

Route the cable to the vehicles ignition.

Step 4

Connect the red ignition sense wire to the vehicle ignition using the spade or ring terminal provided.



CHAPTER 7

Remote Engage Switch Installation

In this chapter:

- Remote engage switch components: Rocker switch
- Remote engage switch components: Foot switch
- Preparing the remote engage cable
- Using the remote engage switch


This chapter describes how to install the remote engage switch.

Remote engage switch components: Rocker switch



Item	Description
❶	DTM receptacle
❷	Remote engage rocker switch

Remote engage switch components: Foot switch




Item	Description
❶	DTM receptacle
❷	Remote engage rocker switch

Preparing the remote engage cable


Step 1

Locate the green 12-pin Deutsch receptacle on the P-5 leg of the main controller harness. For more information, see Chapter 8, Controller Installation.



Step 2


Remove the wedge from the connector.



Step 3


Rocker switch only

Remove the plugs from cavity 2 and cavity 7.



Foot Switch Only


Remove the plugs from cavity 2, cavity 7, and cavity 11.



Step 4


Rocker switch only

Insert the DTM pins into cavity 2 and cavity 7, according to the labels on the wires.




Foot switch only

Insert the DTM pins into cavity 2, cavity 7, and cavity 11, according to the labels on the wires.



Step 5

Pull on the wires to seat them in place and then replace the wedge in the connector.



Step 6

Replace the receptacle on the P5 plug of the NavController II harness.

Step 7

Rocker switch only

Run the spade ends of the cable to a knockout location in the operator console.



Foot switch only


Run the cable to a clear location on the floor board. Use double-sided tape to secure the pedal. Route the cable under the floor mat.



Step 8

Rocker Switch Only

Connect the wires to the switch. Match the print on the switch body with the labels on the wires.



Step 9

Rocker Switch Only

Place the switch in the console.



Using the remote engage switch

To use NavController II to engage the system:

- For firmware versions 5.20 and earlier: Hold down the remote engage switch for longer than **0.5** seconds and less than **4** seconds.
- For firmware 5.21 and later: Hold the switch down for longer than **0.15** seconds and less than **4** seconds.

The system engages when you release the switch.

CHAPTER 8

Controller Installation

In this chapter:

- Installing the controller
- Controller connections

This chapter describes how to install the controller unit.

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information.

Installing the controller

Step 1


The NavController II will be installed behind the seat of the machine.



Step 2


Using the controller mounting plate as a template, mark and drill two 5⁄16" holes for mounting the controller.

Carefully cut 1" holes around the drilled holes for mounting the standoffs.



Step 3

Using the provided hardware and standoffs bolt the controller mounting plate to the machine



Step 4

Attach the main and auxiliary cable harnesses. Use an Allen wrench to secure the connectors to the controller.




Step 5

Attach the NavController II to the controller mounting plate with the connector facing the right side of the vehicle.



Controller connections




Item	Description
1	NavController II controller
P2	Power connector
P3	GNSS connector
P4	Display connector
P5	Vehicle sensors connector
P6	Steering sensor connector
P7	Manual override connector
P8	Hydraulic valve connector

Item	Description
P9	Sonalert connector
P12	Lightbar/spare connector
P13	Spare sensors connector
14	Status indicator
15	Laptop connector
16	Main harness
17	Auxiliary harness

Step 1


Connect the power cable connection to P-2, which is labeled “Power”. P-2 is located on the main wiring harness.

Note – *The power connection supplies power through the controller to all connected devices, including GNSS and displays.*




Step 2

Connect the display cable P/N 75741 to P-3, which is labeled “GPS”. P-3 is located on the main wiring harness.



Step 3


Connect the steering sensor cable connection to P-6, which is labeled “Steering Sensor”. P-6 is located on the main wiring harness.



Step 4


Connect the manual override cable connection to P-7, which is labeled “Manual Override”. P-7 is located on the main wiring harness.

Note – *When you install the remote engage harness, add the pins to the existing connector.*




Step 5

Connect the hydraulic steering valve cable connection to P-8, which is labeled “Hydraulic Valve”. P-8 is located on the main wiring harness.




Step 6

Connect the Sonalert P-9 to the two pin Delphi connector on the main wiring harness. Route the cable so the Sonalert warning device is in a position that is audible to the operator.



Step 7

Route the LED and laptop lead, which is located on the auxiliary wiring harness, to a location that allows the operator to determine the controller status. See controller LED status for status determination. Six flashes per second indicates a correctly functioning controller.



Step 8

Use the provided sleeving to secure the harness cables with tie wraps. Cover and route the cable bundle to avoid damage to connectors and strain on wire connections.

CHAPTER 9

Final Machine Check

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information.

To perform the final machine check:

1. Connect the battery.
2. Start the machine and check for hydraulic leaks. Correct as needed.
3. Update the Trimble display and the Autopilot NavController II to the latest firmware from http://agpartners.trimble.com.

   You can use FlashLoader 200 software version 3.19 to update the Autopilot controller: Download it from http://agpartners.trimble.com.
4. Load the correct configuration file into the Autopilot NavController II for the vehicle model being used.

   Download the latest set of configuration files from http://agpartners.trimble.com.

   You can use Autopilot Toolbox II software version 2.92 or later to load the configuration file into the Autopilot controller. You can download the AutoPilot Toolbox II software from http://agpartners.trimble.com.
5. Calibrate the Autopilot system using the Trimble display or Autopilot Toolbox II software version 2.92 or later. Depending on your machine type, the following items must be calibrated before you can use the Autopilot system:

   –NavController II mounting orientation

   –Manual override

   –Autosense mounting orientation

   –Valve deadzone

   –Autopilot P-gain

   –Antenna height/Antenna axle offset, and Roll offset