Installation Instructions

*Ag*GPS® Autopilot™ Automated Steering System

Apache 2005

- **750**
- **850**

Apache 2006 – 2009

- **710**
- **715**
- **1010**
- **1210**

Version 4.00
Revision B
October 2009
Part Number 54037-80-E04

Trimble®

Agriculture Business Area

Trimble Agriculture Division
10355 Westmoor Drive
Suite #100
Westminster, CO 80021
USA
(877) 447-7785 (US toll free)
+1-408-856-6491 (International)
trimble_support@trimble.com
www.trimble.com

Legal Notices

Copyright and Trademarks

© 1999–2009, Trimble Navigation Limited. All rights reserved.

Trimble, the Globe & Triangle logo, *Ag*GPS, and EZ-Guide are trademarks of Trimble Navigation Limited, registered in the United States and in other countries. Autopilot, AutoSense, and FmX are trademarks of Trimble Navigation Limited.
All other trademarks are the property of their respective owners.

Release Notice

This is the October 2009 release (Revision B) of the *Ag*GPS *Autopilot Automated Steering System Installation Instructions*, part number 54037-80-E04. It applies to version 4.00 of the *Ag*GPS Autopilot automated steering system.

The following limited warranties give you specific legal rights. You may have others, which vary from state/jurisdiction to state/jurisdiction.

Product Limited Warranty

Trimble warrants that this Trimble product and its internal components (the "Product") shall be free from defects in materials and workmanship and will substantially conform to Trimble's applicable published specifications for the Product for a period of one (1) year, starting from the earlier of (i) the date of installation, or (ii) six (6) months from the date of product shipment from Trimble. This warranty applies only to the Product if installed by Trimble or a distributor authorized by Trimble to perform Product installation services.

Software Components and Enhancements

All Product software components (sometimes hereinafter also referred to as "Software") are licensed and not sold. Any Software accompanied by a separate End User License Agreement ("EULA") shall be governed by the terms, conditions, restrictions and limited warranty terms of such EULA notwithstanding the preceding paragraph. During the limited warranty period you will be entitled to receive, at no additional charge, such Fix Updates and Minor Updates to the Product software as Trimble may develop for general release, subject to the procedures for delivery to purchasers of Trimble products generally. If you have purchased the Product from an authorized Trimble distributor rather than from Trimble directly, Trimble may, at its option, forward the software Fix Update or Minor Update to the Trimble distributor for final distribution to you. Major Upgrades, new products, or substantially new software releases, as identified by Trimble are expressly excused from this enhancement process and limited warranty. Receipt of software updates shall not serve to extend the limited warranty period.
For purposes of this warranty the following definitions shall apply: (1) "Fix Update" means an error correction or other update created to fix a previous software version that does not substantially conform to its published specifications; (2) "Minor Update" occurs when enhancements are made to current features in a software program; and (3) "Major Upgrade" occurs when significant new features are added to software, or when a new product containing new features replaces the further development of a current product line. Trimble reserves the right to determine, in its sole discretion, what constitutes a significant new feature and Major Upgrade.

Warranty Remedies

Trimble's sole liability and your exclusive remedy under the warranties set forth above shall be, at Trimble's option, to repair or replace any Product that fails to conform to such warranty ("Nonconforming Product"), and/or issue a cash refund up to the purchase price paid by you for any such Nonconforming Product, excluding costs of installation, upon your return of the Nonconforming Product to Trimble in accordance with Trimble's standard return material authorization process. Such remedy may include reimbursement of the cost of repairs for damage to third-party equipment onto which the Product is installed, if such damage is found to be directly caused by the Product as reasonably determined by Trimble following a root cause analysis.

Warranty Exclusions and Disclaimer

These warranties shall be applied only in the event and to the extent that (i) the Products and Software are properly and correctly installed, configured, interfaced, maintained, stored, and operated in accordance with Trimble's relevant operator's manual and specifications, and; (ii) the Products and Software are not modified or misused. The preceding warranties shall not apply to, and Trimble shall not be responsible for defects or performance problems resulting from (i) the combination or utilization of the Product or Software with hardware or software products, information, data, systems, interfaces or devices not made, supplied or specified by Trimble; (ii) the operation of the Product or Software under any specification other than, or in addition to, Trimble's standard specifications for its products; (iii) the unauthorized, installation, modification, or use of the Product or Software; (iv) damage caused by accident, lightning or other electrical discharge, fresh or salt water immersion or spray; or (v) normal wear and tear on consumable parts (e.g., batteries). Trimble does not warrant or guarantee the results obtained through the use of the Product.

the warranties above state Trimble's entire liability, and your exclusive remedies, relating to performance of the products and software. except as otherwise expressly provided herein, the products, software, and accompanying documentation and materials are provided "as-is" and without express or implied warranty of any kind by either trimble navigation limited or anyone who has been involved in its creation, production, installation, or distribution including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, title, and noninfringement. the stated express warranties are in lieu of all obligations or liabilities on the part of trimble arising out of, or in connection with, any products or software. some states and jurisdictions do not allow limitations on duration or the exclusion of an implied warranty, so the above limitation may not apply to you.

trimble navigation limited is not responsible for the operation or failure of operation of gps satellites or the availability of gps satellite signals.

Limitation of Liability

trimble's entire liability under any provision herein shall be limited to the amount paid by you for the product or software license. To the maximum extent permitted by applicable law, in no event shall trimble or its suppliers be liable for any indirect, special, incidental or consequential damages whatsoever under any circumstance or legal theory relating in any way to the products, software and accompanying documentation and materials, (including, without limitation, damages for loss of business profits, business interruption, loss of business information, or any other pecuniary loss), regardless whether trimble has been advised of the possibility of any such loss and regardless of the course of dealing which develops or has developed between you and trimble. Because some states and jurisdictions do not allow the exclusion or limitation of liability for consequential or incidental damages, the above limitation may not apply to you.

note: the above limited warranty provisions may not apply to products or software purchased in the european union. please contact your trimble dealer for applicable warranty information.

Notices

Class B Statement – Notice to Users. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes and modifications not expressly approved by the manufacturer or registrant of this equipment can void your authority to operate this equipment under Federal Communications Commission rules.

Notice to Our European Union Customers

For product recycling instructions and more information, please go to: www.trimble.com/ev.shtml

Recycling in Europe: To recycle Trimble WEEE, Call +31 497 53 2430, and ask for the "WEEE Associate"
Or
Mail a request for recycling instructions to:
Trimble Europe BV
c/o Menlo Worldwide Logistics
Meerheide 45
5521 DZ Eersel, NL



Safety Information

Always follow the instructions that accompany a Warning or Caution. The information they provide is intended to minimize the risk of personal injury and/or damage to property. In particular, observe safety instructions that are presented in the following format:

WARNING – This alert warns of a potential hazard, which, if not avoided, can cause severe injury.

CAUTION – This alert warns of a hazard or unsafe practice which, if not avoided, can cause injury or damage.

***Note** – An absence of specific alerts does not mean that there are no safety risks involved.*

Warnings

WARNING – When you are working on the vehicle's hydraulic systems, vehicle attachments that are suspended can drop. If you are working around the vehicle, you could suffer serious injury if an attachment dropped on you. To avoid this risk, lower all vehicle attachments to the ground before you begin work.

WARNING – If someone else attempts to drive the vehicle while you are working on or under it, you can suffer serious or fatal injuries. To avoid this possibility, install a lockout box on the battery terminal to prevent the battery from being reconnected, remove the key from the vehicle's ignition switch, and attach a "Do not operate" tag in the cab.

WARNING – Agricultural chemicals can pose serious health risks. If the vehicle has been used to apply agricultural chemicals, steam clean the vehicle to remove any chemical residue from the areas of the vehicle where you will be working.

WARNING – Vehicle cabs can be quite high in the air. To avoid potentially serious injury through falling from this height, always use the steps and handrails, and face the vehicle, when you enter or exit it.

Cautions

CAUTION – When the vehicle has been running, parts of the vehicle, including the engine and exhaust, can become extremely hot and can cause serious burns. To avoid burns, allow hot machine parts to cool before you begin working on them.

CAUTION – The system installation may bring you into contact with chemical substances, such as oil, which can cause poisoning. Wash your hands thoroughly after you finish working on the system.

CAUTION – Battery posts, terminals, and related accessories contain lead and lead compounds, which can cause serious illness. To avoid ingesting lead, wash your hands thoroughly after touching the battery.

CAUTION – Always wear protective equipment appropriate to the job conditions and the nature of the vehicle. This includes wearing protective glasses when you use pressurized air or water, and correct protective welder's clothing when welding. Avoid wearing loose clothing or jewelry that can catch on machine parts or tools.

CAUTION – Parts of the vehicle may be under pressure. To avoid injury from pressurized parts, relieve all pressure in oil, air, and water systems before you disconnect any lines, fittings, or related items. To avoid being sprayed by pressurized liquids, hold a rag over fill caps, breathers, or hose connections when you remove them. Do not use your bare hands to check for hydraulic leaks. Use a board or cardboard instead.

Contents

Safety Information 3

Warnings 3
Cautions 3

1 Introduction 9

Technical assistance 10
Your comments 10
Manual system upgrade to Autopilot 11
EZ-Guide 500 manual guidance upgrade 11
FmX integrated display 11
Required components 11
Antenna mounting kits 11
Accessory kits 11
Autopilot hardware organization: As shipped 12
Autopilot hardware organization: As installed 13
Preparing the vehicle for installation 13

2 Hydraulic Control Valve Installation 15

Hydraulic components: prior to (and including) 2005 models 16
Hydraulic components: 2006 – 2009 and later models 17
Preparing the hydraulic control valve 18
Installing the hydraulic manifold: for all models 19
Connecting the hydraulic hoses: for models up to, and including, 2005 models 21
Connecting the hydraulic hoses: for models 2006 – 2009 and later 27
Securing the electrical connectors: for all models 33

3 AutoSense Steering Device Installation 35

AutoSense steering device components 36
Installing the AutoSense steering device 37
Preparing the harness (P/N 54602 Rev C) 39

4 Antenna/Receiver Installation 41

Antenna and receiver installation options 42
Possible mounting methods 42
Mounting an adjustable spar to roof bolts 43
Attaching the plate with VHB adhesive 45
AgGPS 262 GPS receiver with AgGPS 450/900 radio module (if equipped) components 47
Installing the AgGPS 262 GPS receiver with AgGPS 450/900 radio module (if equipped) 48
Removable installation 48
Permanent installation 49
Installing an AgGPS 262 receiver with magnetic feet 53
AgGPS 432/442 receiver components 55

Installing the AgGPS 432/442 receiver 56
Installing a PDL radio modem 60

5 Display Installation 63

FmX integrated display components 64
EZ-Guide 500 lightbar components 65
With SNB900 radio for 900 MHz RTK corrections (if equipped) 65
With a PDL 450 radio for 450 MHz RTK corrections (if equipped) 66
Preparing the FmX integrated display 67
Installing the FmX integrated display 68
FmX integrated display: Installing the wiring harness 68
FmX integrated display: Connecting accessory options 70
AgCam 70
Speaker 71
Preparing the EZ-Guide 500 lightbar 72
Connecting the EZ-Guide 500 lightbar cables 73
Installing the EZ-Guide 500 lightbar 76
EZ-Guide 500 lightbar and FmX integrated display: Installing the GPS antenna and plate . . . 78
Spar mount method 78
VHB adhesive method. 78
FmX integrated display: Installing the RTK radio antenna 82
EZ-Guide 500 lightbar: Installing a PDL radio modem. 83

6 Power Harness Installation 85

FmX integrated display components 86
EZ-Guide 500 lightbar components 87
Installing the power harness for the FmX integrated display. 88
Configuring the power bus options for the FmX integrated display 90
FmX integrated display power button is used to turn on the Autopilot system 90
External switch is used to turn on the Autopilot system 90
Ignition is used to turn on the Autopilot system 92
Configuring the power bus options for the EZ-Guide 500 lightbar 94

7 Remote Engage Switch Installation 99

Remote engage switch components: Rocker switch 100
Remote engage switch components: Foot switch 101
Preparing the remote engage cable 102
Using the remote engage switch. 105

8 Controller Installation. 107

Installing the controller 108
Controller connections 110
Connecting the cables to the controller 111

9 Final Machine Check 115
Performing the final machine check 116

CHAPTER

1

Introduction

- Technical assistance
- Your comments
- Manual system upgrade to Autopilot
- Required components
- Autopilot hardware organization: As shipped
- Autopilot hardware organization: As installed
- Preparing the vehicle for installation

This manual describes how to install the Trimble® *Ag*GPS® Autopilot™ automated steering system.

Even if you have used other Global Positioning System (GPS) products before, Trimble recommends that you spend some time reading this manual to learn about the special features of this product. If you are not familiar with GPS, visit the Trimble website (www.trimble.com) for an interactive look at Trimble and GPS.

Technical assistance

If you have a problem and cannot find the information you need in the product documentation, contact Trimble technical support:

1. Go to the Trimble website (www.trimble.com).
2. Click the **Support & Training** link at the top of the screen, select *Support* and then select *Support A–Z list of products*.
3. Scroll to the bottom of the list.
4. Click the *submit an inquiry* link. A form appears.
5. Complete the form and then click **Send**.

Your comments

Your feedback about the supporting documentation helps us to improve it with each revision. Email your comments to ReaderFeedback@trimble.com.

Manual system upgrade to Autopilot

EZ-Guide 500 manual guidance upgrade

Retain	Remove
*Ag*GPS® EZ-Guide® 500 lightbar P/N 66100-xx Antenna for EZ-Guide 500 lightbar: P/N 60600-xx (DGPS) or 57200-00 (OmniStar/RTK) Antenna to receiver cable: P/N 50449 Power cable: P/N 62817 *Optional.* Remote keypad	Power connection cable: P/N 62818

FmX integrated display

Retain	Remove
Trimble® FmX™ integrated display: P/N 93100-xx Antenna for FmX integrated display: P/N 60600-02 (DGPS) or 57970-00 (OmniStar/RTK) Antenna to receiver cable: P/N 50449 Power cable: P/N 67258 & 66694	

Required components

Kits required	Special tools
Platform kit: P/N 54037-80 Hydraulic hose kit: P/N 75758	$^{5}/_{16}$'' drill bit 5000 psi hydraulic gauge and extension hose Allen wrench sets (metric and SAE) Right angle drill or right angle extension

Antenna mounting kits

Antenna options
Antenna spar mount: P/N 55348
Antenna V plate mount and *Ag*GPS 262 receiver magnetic mount: P/N 62388-01 (includes magnets for quick release of the *Ag*GPS 262 receiver – see Chapter 4, Antenna/Receiver Installation).

Accessory kits

Accessory options
Remote engage switch assembly – standard Euro: P/N 57227-10
Remote engage switch assembly – full Euro: P/N 57227-20
Remote engage foot pedal: P/N 57259

Autopilot hardware organization: As shipped

Hardware	Component	See...
Platform kit **(P/N 54037-80)**	Hydraulic valve	Chapter 2
	Hydraulic manifold	Chapter 2
	Transducer flow switch	Chapter 2
	Manual override cable	Chapter 2
	Hydraulic brackets and bolt kits	Chapter 2
	Hydraulic valve cable	Chapter 2
	AutoSense™ steering device and cabling	Chapter 3
	AutoSense mounting bracket and hardware	Chapter 3
	Power cable and switch	Chapter 6
	Bolt kit controller	Chapter 8
Common parts	Controller	Chapter 8
	Controller mounting bracket	Chapter 8
	Cable kit: • Main wiring harness • Auxiliary wiring harness • Sonalert alarm	Chapter 8
GPS receiver	GPS receiver	Chapter 4
	GPS antenna	Chapter 4
	GPS receiver mounting bracket	Chapter 4
	GPS receiver power/data cable	Chapter 4
	RTK radio, cable, and radio antenna	Chapter 4
Display	EZ-Guide 500 lightbar	Chapter 5
	FmX™ integrated display	Chapter 5
	Display cable	Chapter 5
	Mounting bracket	Chapter 5
Hydraulic hose kit **(P/N 75758)**	Hydraulic hoses	Chapter 2
	Hydraulic adaptors	Chapter 2
Roof bracket kit **(P/N 55348)**	Roof brackets	Chapter 4
	Bolt kit, roof bracket	Chapter 4

Autopilot hardware organization: As installed

Hardware	Component	See...
Hydraulics	• Hydraulic valve, manifold, pressure transducer, or flow switch • Hydraulic valve cable • Manual override cable • Hydraulic brackets and bolt kits	Chapter 2
AutoSense steering device	• AutoSense steering device and cabling • AutoSense mounting brackets and hardware	Chapter 3
GPS receiver	• GPS receiver • GPS antenna • GPS receiver mounting bracket • GPS receiver power/data cable • Roof brackets	Chapter 4
Display	• *Ag*GPS EZ-Guide 500 lightbar • FmX integrated display • Display cable(s) • Mounting bracket	Chapter 5
Power	• Power bus and switch	Chapter 6
Controller	• Controller • Mounting plate • Bolt kit - controller • Main wiring harness • Aux. wiring harness • Sonalert alarm	Chapter 8

Preparing the vehicle for installation

Step 1

Park the vehicle on a hard, level surface. Block the front and rear wheels.

Step 2

Align the steering straight ahead. On an articulated vehicle, install the articulation locks.

Step 3

Remove all dirt and debris from the areas of the vehicle where the *Ag*GPS Autopilot™ system will be installed.

Step 4

Open all kit boxes and check the contents of the box against the packing list/s. Lay all of the parts out on a clean workbench.

Note – *The left and right sides of the vehicle are referenced while standing behind the unit, facing the normal direction of travel.*

CHAPTER

2


Hydraulic Control Valve Installation

In this chapter:

- Hydraulic components: prior to (and including) 2005 models
- Hydraulic components: 2006 – 2009 and later models
- Preparing the hydraulic control valve
- Installing the hydraulic manifold: for all models
- Connecting the hydraulic hoses: for models up to, and including, 2005 models
- Connecting the hydraulic hoses: for models 2006 – 2009 and later
- Securing the electrical connectors: for all models

This chapter describes the configuration and installation of the valve, manifold and hydraulic hose kit.

Hydraulic components: prior to (and including) 2005 models



Item	Description	Part number
❶	52" hose	F451TC0639-08-08-08-52
❷	26" hose	F451TC0606-08-08-08-26
❸	37" hose (optional)	F451TC0637-08-08-08-37
❹	30" hose (x2)	F451TC0639-06-06-06-30
❺	Fitting	-8 F5OX-S
❻	Fitting	-8 C5OX-S


Item	Description	Part number
❼	Fitting	-8 VOX-S
❽	Fitting (x2)	-6–8 F5OX-S
❾	Fitting	-8 R6X-S
❿	Fitting (x2)	-6 R6X-S
⓫	Fitting (optional)	-8 C6X-S
⓬	Fitting	-8 HTX-S

Notes:

– *Hose #3 may not be required.*

– *Part numbers are Parker numbers and are for reference only.*

Hydraulic components: 2006 – 2009 and later models



Item	Description	Part number
❶	52" hose	F451TC0639-08-08-08-52
❷	26" hose	F451TC0606-08-08-08-26
❸	37" hose (optional)	F451TC0637-08-08-08-37
❹	30" hose (x2)	F451TC0639-06-06-06-30
❺	Fitting	-8 F5OX-S
❻	Fitting	-8 C5OX-S

Item	Description	Part number
❼	Fitting	-8 VOX-S
❽	Fitting (x2)	-6–8 F5OX-S
❾	Fitting	-8 R6X-S
❿	Fitting (x2)	-6 R6X-S
⓫	Fitting (optional)	-8 C6X-S

Notes:

- *Hose #3 may not be required.*
- *Part numbers are Parker numbers and are for reference only.*

Preparing the hydraulic control valve

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information chapter.

Step 1

Locate PFRD cartridge. It will be stamped “PFRD-12-4-0-000-110-00”.



Step 2

Install the PFRD cartridge into the manifold sandwich plate.



Installing the hydraulic manifold: for all models

Step 1

Use the two existing bolts that support the fuel tank on the left side of the machine to mount the *Ag*GPS Autopilot hydraulic manifold.



Step 2

The fuel tank must be supported before the two bolts are removed.



Step 3

Remove the two nuts and bolts from the fuel tank support bracket.

Slide the manifold bracket into place and reinstall the tank bolts.

Note – *Position the manifold bracket so that the larger manifold bolt holes are top/rear and bottom/front.*


Tighten the fuel tank bolts securely



Step 4

Use the supplied $^{3}/_{8}$"–16 bolts and washers (❶) to attach the *Ag*GPS Autopilot manifold assembly to the bracket.

Note – *With this install, the valve solenoids were rotated to better protect the wires.*



Connecting the hydraulic hoses: for models up to, and including, 2005 models

Step 1

Install a -8 45° SAE–JIC adaptor in the T port of the *Ag*GPS Autopilot manifold, orientated as shown.




Step 2

Connect one end of the 26" tank hose to the adaptor on the T port and then route the hose up and back towards the existing distribution manifold.



Step 3

Locate the "T" line on the distribution manifold.



Step 4

Disconnect the existing tank line and insert a -6 JIC run T-fitting and reconnect the existing tank line to the free end of the T-fitting.

Connect the end of the new tank line routed up from the hydraulic manifold to the branch of the T-fitting.

Note – *An optional 90° elbow is supplied for routing the T hose, if required.*



Step 5


Locate the pressure port on the steering pump.

Disconnect the existing pressure hose from the steering pump and route it through to the *Ag*GPS Autopilot hydraulic manifold.



Step 6

Install a 90° SAE–JIC adaptor to the EF port on the *Ag*GPS Autopilot hydraulic manifold, orientated as shown.



Step 7

Connect the end of the pressure hose to the EF port on the *Ag*GPS Autopilot manifold.




Step 8

Install a -8 SAE–JIC adaptor in the P port of the *Ag*GPS Autopilot manifold and then attach the 90° end of the 52" long pressure hose to the adaptor, orientated as shown.



Step 9

Connect the 37" -8 hose to the pressure port on the steering pump and then add a -8-8 JIC coupler to the free end of the hose.



Step 10

Connect the coupler added in Step 9 to the free end of the 52" hose that was connected to the P port of the *Ag*GPS Autopilot manifold in Step 8.

Step 11

Install -8–6 SAE–JIC adaptors to the A and B ports on the *Ag*GPS Autopilot manifold.



Step 12

Attach a -6 JIC run T-fitting to each of the adaptors installed in the A and B ports.



Step 13

Locate where the "A" and "B" cylinder hoses connect to the top of the distribution manifold.


Remove the hose from the right-hand 90° fitting.

Remove the tie-wraps, as required, to allow the hose to be relocated to the T-fitting installed in Step 12.



Step 14

Connect the hose to the branch of the run T-fitting on the B port (❶) of the hydraulic manifold as shown.



Step 15

Repeat Step 13 and Step 14 for the left-hand hose connected to the top of the distribution manifold, but connect it to the run T-fitting on the A port (❷) of the hydraulic manifold as shown.


Step 16

Connect the two 30" A and B hoses to the ends of the run T-fitting at the *Ag*GPS Autopilot manifold as shown and then route the hoses to the distribution manifold.



Step 17


Connect the straight end of A hose to the left-side fitting (❶) and the straight end of the B hose to the right-side fitting (❷) on top of the distribution manifold.



Step 18

Remove the port plug from the GP-EF port on the *Ag*GPS Autopilot manifold.

Note – *It may help to strike the plug with a ball-pein hammer to loosen it.*



Step 19

Install the pressure transducer into the GP-EF port of the *Ag*GPS Autopilot manifold.



Connecting the hydraulic hoses: for models 2006 – 2009 and later

Step 1

Install a -8 45° SAE–JIC adaptor in the T port of the *Ag*GPS Autopilot manifold, orientated as shown.




Step 2

Connect one end of the 26" tank hose to the adaptor and then route the hose up and back towards the existing distribution manifold.



Step 3

Locate the "T" line on the distribution manifold.



Step 4

Disconnect the existing tank line and insert a -6 JIC run T-fitting and reconnect the existing tank line to the free end of the T-fitting.

Connect the end of the new tank line routed up from the hydraulic manifold to the branch of the T-fitting.

Note – *An optional 90° elbow is supplied for routing the T hose, if required.*



Step 5

Install a -8 SAE–JIC adaptor in the P port of the *Ag*GPS Autopilot manifold. Attach the 90° end of the 52" long pressure hose to the adaptor, orientated as shown.



Step 6

Locate the "OUT" port on the hydraulic oil filter and remove the existing hose.


Attach the loose end of the pressure hose installed in Step 8 to the existing 90° fitting.

CAUTION – Route the hose away from the drive shaft or any other moving parts.



Step 7

Install a 90° SAE–JIC adaptor to the EF port on the *Ag*GPS Autopilot manifold, orientated as shown.



Step 8

If the end of the pressure hose removed from the hydraulic filter in Step 6 can be routed to reach the newly installed 90° adaptor on the EF port, it can be reused.

If it will not easily reach the adaptor, replace it with a 37" -8 pressure hose as shown in the hydraulic diagram on page 17.



Step 9

Install -8–6 SAE–JIC adaptors to the A and B ports on the *Ag*GPS Autopilot manifold.



Step 10

Attach a -6 JIC run T-fitting to each of the adaptors installed in the A and B ports.



Step 11

Locate where the "A" and "B" cylinder hoses connect to the top of the distribution manifold.

Remove the hose from the right-hand 90° fitting.

Remove the tie-wraps, as required, to allow the hose to be relocated to the T-fitting installed in Step 12.




Step 12

Connect the hose to the run T-fitting on the B port (❶) of the hydraulic manifold as shown.

Step 13

Repeat Step 13 and Step 14 for the left-hand hose connected to the top of the distribution manifold, but connect it to the run T-fitting on the A port (❷) of the hydraulic manifold as shown.




Step 14

Connect the two 30" A and B hoses to the ends of the run T-fitting at the *Ag*GPS Autopilot manifold as shown and then route the hoses to the distribution manifold.



Step 15


Connect the A hose to the left-side fitting (❶) and the B hose to the right-side fitting (❷) on top of the distribution manifold.



Step 16

Remove the port plug from the GP-EF port on the *Ag*GPS Autopilot manifold.

Note – *It may help to strike the plug with a ball pane hammer to loosen it.*



Step 17

Install the pressure transducer into the GP-EF port of the *Ag*GPS Autopilot manifold.



Securing the electrical connectors: for all models

Step 1


The steering valve cables are marked "Valve A" and "Valve B".

Connect the "Valve A" cable to the "A" solenoid (front of the machine) and the "Valve B" cable to the "B" solenoid.



Step 2

Connect the transducer cable to the transducer.



Step 3

Be sure that all the hydraulic connections are tight.

Check the level of the machine hydraulic oil, and add oil as required.

Reconnect the battery and start the machine to check for hydraulic leaks. Disconnect the battery after the leak check has been performed.

CHAPTER

3

AutoSense Steering Device Installation

In this chapter:

- AutoSense steering device components
- Installing the AutoSense steering device
- Preparing the harness (P/N 54602 Rev C)

This chapter describes how to install the *Ag*GPS AutoSense™ steering device.


If the described mounting location is not accessible, chose a different place. To ensure proper function, the AutoSense device must be located where it is free of obstructions and can rotate with the wheels when they turn.

On articulated vehicles, mount the AutoSense device on the opposite side of the pivot point to the Autopilot controller.

Mount the device base down or base up so that it maintains a level orientation. Do not mount it on its side. An angle of up to 10° in any direction is acceptable.

To avoid stretching the cable, leave adequate length on the service loop.

AutoSense steering device components



Item	Description	Trimble part number
❶	P-6 connector	
❷	Power connector	
❸	AutoSense connector	
❹	Jumper cable	57560
❺	AutoSense steering cable	57885

Installing the AutoSense steering device

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information chapter.

Step 1

Locate the tie-rod nut on the right-hand side of the machine.



Step 2

Remove the split-pin and castle nut from the tie rod joint. Replace the castle nut with the Autosense tie-rod mount stud and re-install the split-pin.



Step 3

Use the supplied $^{3}/_{8}$"–16 mm bolt and blue Loctite to attach the Autosense mount plate.

Note – *Ensure the mount plate is installed square to the machine.*



Step 4

Use four of the supplied socket-head cap screws to attach the sensor to the mount plate.




Step 5

Route the steering cable to the steering sensor along the existing hoses and then connect it to the steering sensor. Leave adequate length on the service loop to avoid stretching the cable.



Step 6


Connect the steering device cable connection to P-6 on the main wiring harness. P-6 is labeled “Steering Sensor”.



Preparing the harness (P/N 54602 Rev C)


Step 1

Remove the black Deutsch DTM receptacle from the P-13 sensors leg of the auxiliary harness. See Chapter 8, Controller connections.




Step 2

Remove the plug from cavity number 1.




Step 3

Remove the wedge from the connector.




Step 4

Insert the DTM pin labeled "Cavity 1" into the connector.



Step 5

Pull back on the wire to seat the pin. Replace the wedge in the connector.



CHAPTER

4

Antenna/Receiver Installation

In this chapter:

- Antenna and receiver installation options
- AgGPS 262 GPS receiver with AgGPS 450/900 radio module (if equipped) components
- Installing the AgGPS 262 GPS receiver with AgGPS 450/900 radio module (if equipped)
- Installing an AgGPS 262 receiver with magnetic feet
- AgGPS 432/442 receiver components
- Installing the AgGPS 432/442 receiver
- Installing a PDL radio modem

This chapter describes how to install an *Ag*GPS 262 receiver and *Ag*GPS radio module, an *Ag*GPS 332 receiver and antenna, or an *Ag*GPS 442 receiver and antenna.

Note – *To install the antenna for an EZ-Guide 500 system, see Chapter 5, Display Installation.*

Antenna and receiver installation options

There are several options for mounting components (the antenna, radio module, or GPS receiver) on the cab roof depending on the accuracy required and the antenna type:

- **Spar mount** – This bracket mounts directly to the roof bolts and is required for all high accuracy applications such as RTK and OmniSTAR. Trimble recommends this method for mounting an *Ag*GPS 262 receiver. Bolt a metal spar to the roof or to a light bracket and then attach either a V plate for magnetic mounting or an *Ag*GPS 262 receiver plate for permanent mounting.
- **VHB mount** – Attach a 4" x 6" plate or a V plate directly to the roof with VHB (Very High Bond) adhesive for magnetic mounting. See page 45.
- **Magnetic mounting** – Magnetic mounting for quick release is available for both VHB and spar type mounting:

Possible mounting methods

GPS receiver	V plate on spar (removable)	VHB plate on roof (removable)	Standard *Ag*GPS 262 plate bolted to spar (permanent)
*Ag*GPS 262 receiver	✓	X	✓
*Ag*GPS 432/442 receiver	✓	X	X
EZ-Guide 500 lightbar	✓	✓	X
FmX integrated display	✓	✓	✓

Notes:

– *For quick release magnetic mounting with an AgGPS 262 receiver, order the kit listed in Antenna mounting kits, page 11 and bolt the V plate to the spar. When spar mounting is not available and high accuracy is required, see Installing an AgGPS 262 receiver with magnetic feet, page 53.*

– *With all other antennas, bolt the V plate to the spar for high accuracy and repeatability.*


– *For WAAS, EGNOS, OmniSTAR VBS, Beacon, and DGPS applications, place either of the plates in a firm location using the VHB.*

Mounting an adjustable spar to roof bolts

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information chapter.

Step 1

Locate the position of the cab bolts on the roof of the vehicle.



Step 2

Remove the existing roof bolts and position the spar in line the large washers.



Step 3

Use the supplied ½"–13 x 1¼" long bolts and two 1.75 x .75 washers to secure the spar to the cab roof.

Note – *If the receiver is offset to the left or the right of the vehicle, AgGPS Autopilot system performance may be affected. Before you tighten the cab bolts, make sure that the GPS antenna is aligned with the center of the vehicle.*



Step 4

For either of the following applications:


- A single magnet antenna mount
- An *Ag*GPS 262 receiver with magnetic option for quick removal

Attach a V plate with four ¼" flathead screws.

The narrow end points to the front of the vehicle.



V plate on the spar



Magnetic mount on the V plate

If you use a standard *Ag*GPS 262 plate for permanent mounting, install the radio antenna first. Use four ¼" flathead screws to attach the plate, with the handle toward the back of the vehicle.




Plate on the spar

Attaching the plate with VHB adhesive

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information chapter.

Standard 4" x 6" plates are provided in most kits. You can use the VHB mounting method to attach either a 4" x 6" plate or a V plate.

- **L1/L2 dual band antenna (RTK, OmniSTAR, DGPS)** – To use this method for high accuracy, the surface must be rigid and free of "oil panning". For RTK or OmniSTAR HP corrections, the spar method is recommended. The V plate provides repeatable positioning of the antenna.
- **L1 single band antenna (WAAS, EGNOS, OmniSTAR VBS, Beacon)** – Use a 4" x 6" plate for simplified installation in applications where high accuracy is not critical.

Step 1

Clean the antenna location on the roof of the cab with a light solvent to remove oil and dust. Apply force to the roof to find a firm location.




Step 2

V plate only

Remove the backing from one side of the VHB strips provided and then apply the strips to the plate.


Note – *The VHB strips are pre-applied to the 4" x 6" plate.*




Step 3

Remove the backing from the other side of the VHB strips and then apply the plate to the cab roof. The narrow end of the plate points forward. Ensure that the VHB strips make even contact with the surface. Apply pressure and then leave for approximately 30 minutes to adhere.

Note – *The arrow points to the front of the vehicle.*




V plate



4" x 6" plate

*Ag*GPS 262 GPS receiver with *Ag*GPS 450/900 radio module (if equipped) components



Item	Description	Trimble part number
❶	*Ag*GPS 450 or 900 radio (if equipped)	
❷	Radio antenna cable and magnetic mount	
❸	*Ag*GPS 450 or 900 radio antenna	
❹	Antenna/receiver cable	54608
❺	*Ag*GPS Autopilot controller	
❻	*Ag*GPS 262 antenna/receiver	

Installing the *Ag*GPS 262 GPS receiver with *Ag*GPS 450/900 radio module (if equipped)

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information chapter.

To attach the *Ag*GPS 262 receiver plate to the cab roof, do one of the following:

- For a removable installation, attach a V plate to a spar and then stick the receiver plate to the V plate with magnets.
- For a permanent installation, bolt the receiver plate to a spar.

Removable installation

Step 1

V plate

Attach the V plate to the spar using the ¼" flathead screws provided in the V plate bolt kit. Ensure that the narrow end points forward.

For spar mounting instructions, see page 43.



Mounting plate

Attach the three provided magnets to the plate with the ¼" flathead screws and hardware provided.



Underside of plate

Permanent installation

Step 1

Use the four provided ¼" flathead screws ❶ to attach the receiver mounting bracket to the spar.


For spar mounting instructions, see page 43.



Step 2

Both installation methods

Place the radio module on the *Ag*GPS 262 receiver. Secure it with the eight screws in the positions shown ❶.




Step 3

Attach the antenna base to the rear of the plate with the two flathead screws provided.



Step 4

Attach the radio antenna to the antenna base.



Step 5

Position the *Ag*GPS 262 receiver and radio on the mounting plate with the connector ports facing the radio antenna. Align the three bolt holes with the receiver, radio, and mounting plate.



Step 6

Insert the nylon bushings provided.




Step 7

Insert the bolts through the receiver, radio, and mounting bracket. Place nuts on the bolt ends and then tighten them.



Step 8

Remove the connector plug from port B ❶.



Step 9

Place the radio module connector into port B of the receiver.



Step 10


Connect the radio antenna to the antenna port.



Step 11

Magnet method

Place the receiver on the roof by aligning the magnets with the V plate. Ensure that the handle ❶ is toward the back of the vehicle.




Step 12

Both methods

Connect the cable from the cab controller into port A ❶ of the *Ag*GPS 262 receiver. Bolt the cable clamp ❷ to the left side of the receiver.

Route the cable into the cab and into the controller.



Installing an *Ag*GPS 262 receiver with magnetic feet

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information chapter.

Use this option only when all other options are unavailable. It requires a firm surface for mounting to avoid vertical vibration and is not an easily repeatable location when moving receivers. Many cabs do not offer roof bolts; you may need to drill or to construct a firm location.

Step 1

Attach the magnets to the receiver mounting plate. Mount the *Ag*GPS 262 GPS receiver using the three ¼" bolts.

Place the nuts on the receiver side.



Step 2

Turn the mounting plate upside down. Stick the covers onto the magnets as shown.




Step 3

Clean the antenna location on the roof of the cab with a light solvent to remove oil and dust.


Remove the backing from the VHB strips and then apply the plates to the cab roof.

Attach the three mounting plates so that the receiver is as firm as possible.




Step 4

Stick the antenna magnetic mounts at the center of the mounting plates.




Step 5

Connect the antenna cable to port A of the *Ag*GPS 262 GPS receiver and then route the cable toward the NavController II harness.



*Ag*GPS 432/442 receiver components



Item	Description	Trimble part number
❶	Radio antenna magnetic base	
❷	Radio antenna	
❸	Radio antenna cable	
❹	*Ag*GPS 432/442 GPS receiver	
❺	Antenna cable	
❻	Receiver cable	62037
❼	To controller “P3 GPS”	
❽	Antenna magnetic mount	
❾	*Ag*GPS 432/442 antenna	

Installing the *Ag*GPS 432/442 receiver


WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information chapter.

Step 1

Attach the large magnet with a $^{5}/_{8}$" stud to the GPS antenna.



If the antenna has magnets built in, skip this step.



Step 2

L1/L2 dual band antenna (RTK, OmniSTAR, DGPS)

For repeatable positioning, place the antenna against the lip at the narrow end of the V plate.



Step 3

Attach the antenna/receiver cable to the antenna and then route the cable into the cab through the rubber grommet at the base of the rear window. Secure the cable along the way.



Step 4

Mount the receiver in a convenient location in the cab. Route the antenna cable to the receiver and then connect it.




Step 5

Identify the correct adaptor for the radio connection:

❶ Reverse polarity TNC-to-N for 900 MHz radios

❷ Normal polarity TNC-to-N for 400 MHz radios



Step 6

Attach the adaptor to the radio port.



Step 7

Connect the radio antenna cable to the radio port adaptor.



Step 8

Connect the controller cable to the 26-pin connector of the receiver. Controller cable connections will be completed later in the section Controller connections.



Step 9

Connect the radio antenna to the magnetic antenna base.



Step 10

Attach the magnetic radio antenna base to the rear of the V plate on the roof. If the cable does not reach the V plate, use the 4" x 6" plate with the VHB provided to relocate the antenna.



Installing a PDL radio modem

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information chapter.

Step 1

Position the radio where it is accessible for the operator to select a new radio channel ID.



Permanent mount

For a permanent mount, bolt the radio onto a bracket with a $^{5}/_{8}$" UNC screw.




Temporary mount

For a temporary mount (so it can be moved between vehicles), mount the radio on a magnet with a $^{5}/_{8}$" UNC stud.



Step 2

Connect the radio antenna cable adaptor to the radio.



Step 3

Connect the radio cable to the adaptor.



CHAPTER

5


Display Installation

In this chapter:

- FmX integrated display components
- EZ-Guide 500 lightbar components
- Preparing the FmX integrated display
- Installing the FmX integrated display
- FmX integrated display: Installing the wiring harness
- FmX integrated display: Connecting accessory options
- Preparing the EZ-Guide 500 lightbar
- Connecting the EZ-Guide 500 lightbar cables
- Installing the EZ-Guide 500 lightbar
- EZ-Guide 500 lightbar and FmX integrated display: Installing the GPS antenna and plate
- FmX integrated display: Installing the RTK radio antenna
- EZ-Guide 500 lightbar: Installing a PDL radio modem

This chapter describes and how to install and connect the FmX integrated display, or the EZ-Guide 500 lightbar in the vehicle.

FmX integrated display components




Item	Description
❶	FmX integrated display: P/N 93100-02
❷	FmX power cable: P/N 66694
❸	GPS, 5M, TNC/TNC RT angle cable: P/N 50449
❹	GPS antenna: P/N 57200-00
❺	Antenna cable and base: P/N 62120
❻	SNB900 radio antenna kit: P/N 28822-10
❼	FmX to NavController II cable w/ port replicator: P/N 65522
❽	NavController II main cable: P/N 54601
❾	NavController II: 55563-00

Item	Description
❿	FmX power cable w/ relay and switch: P/N 67259
⓫	FmX basic power cable: P/N 67258
⓬	Switch cable: Incl with P/N 67259
⓭	Switch - optional: Incl with P/N 67259 (illuminated switch sold separately)
⓮	Ignition sense cable: Incl with P/N 67259
⓯	FmX to camera cable: P/N 67090
⓰	AgCam (purchased separately)
⓱	External speaker

EZ-Guide 500 lightbar components


With SNB900 radio for 900 MHz RTK corrections (if equipped)



Item	Description
❶	EZ-Guide 500 lightbar
❷	GPS antenna: P/N 57200-00
❸	SNB900 radio antenna: P/N 22882-00
❹	SNB900 radio antenna magnetic mount: P/N 62109
❺	GPS antenna cable: P/N 50449
❻	N Female to REV. POL TNC Male: P/N 62114
❼	SNB900 radio: P/N X8480-X0
❽	Remote keypad (optional): P/N 66030-00)

Item	Description
❾	External interface cable: P/N 62749
❿	Radio power/data cable: P/N 61158
⓫	EZ-Guide 500 power cable: P/N 62817
⓬	EZ-Guide 500-to-Autopilot cable: P/N 62754
⓭	NavController II: P/N 55563-00
⓮	Port expansion cable: P/N 62609
⓯	Power tap to PDL radio: P/N 63185

With a PDL 450 radio for 450 MHz RTK corrections (if equipped)



Item	Description
❶	EZ-Guide 500 lightbar
❷	GPS antenna: P/N 57200-00
❸	PDL 450 radio antenna: P/N 5187-x0-x0
❹	Radio antenna magnetic mount: P/N 62109
❺	GPS antenna cable: P/N 50449
❻	Radio antenna connector: P/N 63278
❼	PDL 450 radio: P/N 62550-4x-xx
❽	Remote keypad (optional): P/N 66030-00

Item	Description
❾	External interface cable: P/N 62749
❿	PDL radio power/data cable: P/N 51861-00
⓫	Power tap to PDL radio: P/N 63185
⓬	EZ-Guide 500 power cable: P/N 62817
⓭	EZ-Guide 500-to-Autopilot cable: P/N 62754
⓮	NavController II: P/N 55563-00
⓯	Port expansion cable: P/N 62609

Preparing the FmX integrated display

Step 1

Locate the FmX integrated display, the RAM mount, and the RAM mount clamp.



Step 2

Use the provided metric hardware to attach the RAM mount to the rear of the display.



Step 3

Attach the RAM mount to the rear of the display.



Installing the FmX integrated display

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information chapter.

Step 1

Decide where you will mount the display in the vehicle cab. Use the provided bolts to attach the bar mount to the rail

Step 2

Attach the free end of the RAM mount to the bar mount. Tighten the clamp on the RAM mount so that the display is secure.

FmX integrated display: Installing the wiring harness


Step 1

Locate the cable that connects the FmX integrated display to the *Ag*GPS NavController II ❶.



Step 2


Connect the cable to the P3 connector on the NavController II main harness, and then route the cable from the NavController II to the mounting location on the FmX integrated display.



Step 3

Connect the cable to the C port of the FmX integrated display.

Note – *To connect power to the FmX integrated display, see Chapter 6, Power Harness Installation.*



FmX integrated display: Connecting accessory options

AgCam

The AgCam and AgCam cable are accessory items that you can purchase separately from the FmX integrated display. The FmX integrated display will allow for up to four video inputs.

Step 1

Locate the AgCam and AgCam cable.



Step 2

Mount the AgCam in a secure location and then route the cable towards the FmX integrated display.

Step 3

Connect the AgCam cable to the FmX integrated display adaptor cable.



Step 4

Connect the FmX integrated display to AgCam adaptor cable to one of the open 12 pin connectors on the back of the display.



Speaker

Step 1

Locate the speaker and cable assembly that connects to the FmX integrated display.



Step 2

Mount the speaker in the required location and then route the cable to the FmX integrated display.

Step 3

Connect the speaker cable to one of the open 12 pin connectors on the back of the display.



Preparing the EZ-Guide 500 lightbar

Note – *Before you attach the lightbar to the RAM mount, connect the EZ-Guide 500 cables to the back of the lightbar.*

Step 1

Locate the EZ-Guide 500 lightbar, the RAM mount and hardware, and the RAM mount clamp.



Step 2

Attach the RAM mount diamond base to the display using the hardware provided.



Connecting the EZ-Guide 500 lightbar cables

Note – *Before you attach the lightbar to the RAM mount, connect the EZ-Guide 500 cables to the back of the lightbar.*


Step 1

Connect the port expansion cable (P/N 62609) to the AUX port on the back of the lightbar.



Step 2

Connect the EZ-Guide 500 power cable (P/N 62817) to the PWR port on the back of the lightbar.



Step 3

Connect the 2-pin connector on the port expansion cable and the 12-pin connector on the power cable to the matching connectors on the EZ-Guide 500-to-Autopilot cable (P/N 62754).

Step 4


Feed the GPS antenna cable into the cab and then connect it to the antenna port on the back of the lightbar.




Step 5

With keypad

Connect the external interface cable (P/N 66030-00) to the serial port on the back of the lightbar.




Connect the remote keypad to the KPAD serial port on the external interface cable.



Connect the appropriate cable to the GPS serial port on the interface cable:


Radio type	Cable to connect
SNB900 radio	EZ-Guide 500-to-radio cable (P/N 61158)
PDL 450 radio	PDL radio power/data cable (P/N 51861-00)



Without keypad

Connect the appropriate cable to the serial port on the back of the lightbar:

Radio type	Cable to connect
SNB900 radio	EZ-Guide 500-to-radio cable (P/N 61158)
PDL 450 radio	PDL radio power/data cable (P/N 51861-00)



Step 6

Connect the other end of the radio cable to the radio.

Step 7

Connect the remaining connector on the PDL radio power/data cable to the matching connector on the power tap cable (P/N 63185).

Connect the connector at the other end of the power tap cable to the EZ-Guide 500 power cable.

Installing the EZ-Guide 500 lightbar

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information chapter.

Step 1

Select the location for the lightbar in the cab. There must be a bar that the RAM mount can be attached to.



Step 2

Sit in the driver's seat and hold the lightbar in place. Ensure that it allows comfortable access to the display buttons and does not obstruct instruments.



Step 3

Attach the RAM mount to the ball on the rear of the lightbar.



Step 4

Attach the free end of the RAM mount to the bar mount. Tighten the clamp on the RAM mount so that the lightbar is held securely in place.



Step 5

Adjust the angle of the RAM mount for ease of use.



EZ-Guide 500 lightbar and FmX integrated display: Installing the GPS antenna and plate

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information chapter.

Note – *The V plate antenna bracket is available on the Autopilot price list. See* *Antenna mounting kits, page 11*.

Use one of the following methods:

- Spar mount
- VHB adhesive

Spar mount method

Trimble recommends that you use this method for RTK and OmniSTAR operations. For more information, see Antenna and receiver installation options, page 42.

Attach the V plate to the spar with the four supplied ¼"-20 flathead screws as shown. The narrow end points forward.



VHB adhesive method

Standard 4" x 6" plates are provided in most kits. You can use Very High Bond (VHB) to attach either a 4" x 6" plate or a V plate.

- **L1/L2 dual band antenna (RTK, OmniSTAR, DGPS)** – To use this method for high accuracy, the surface must be rigid and free of "oil panning". For RTK or OmniSTAR HP corrections, the spar method is recommended. The V plate provides repeatable positioning of the antenna.
- **L1 single band antenna (WAAS, EGNOS, OmniSTAR VBS, Beacon)** – Use a 4" x 6" plate for simplified installation in applications where high accuracy is not critical.

Step 1

Clean the antenna location on the roof of the cab with a light solvent to remove oil and dust.




Step 2

V plate only

Remove the backing from one side of the VHB strips provided and then apply the strips to the plate.


Note – *The VHB strips are pre-applied to the 4" x 6" plate.*




Step 3

Remove the backing from the other side of the VHB strips and then apply the plate to the cab roof. The narrow end points forward. Ensure that the VHB strips make even contact with the surface. Apply pressure and then leave for approximately 30 minutes to adhere.

Note – *The arrow in this figure points to the front of the vehicle.*




V plate



4" x 6" plate

Step 4

If the antenna has magnets built in, omit this step.



Otherwise, attach the large magnet with a $^{5}/_{8}$" stud to the GPS antenna.



Step 5

L1/L2 dual band antenna (RTK, OmniSTAR, DGPS)

For repeatable positioning, place the antenna against the lip at the narrow end of the V plate.



L1 single band antenna (WAAS, EGNOS, VBS, Beacon)

Attach the antenna to the center of the 4" x 6" plate.



Step 6

Both models

Attach the antenna/receiver cable to the antenna and then route the cable into the cab through the rubber grommet at the base of the rear window. Secure the cable along the way.



FmX integrated display: Installing the RTK radio antenna

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information chapter.

Step 1

Connect the radio antenna to the magnetic antenna base



Step 2

Attach the magnetic radio antenna base to the rear f the V plate on the roof. If the cable does not reach the V plate, use the 4" x 6" plate with the VHB provided to relocate the antenna.



Step 3

Route cable from the vehicle roof into the cab, and connect the radio cable to the FmX integrated display.

EZ-Guide 500 lightbar: Installing a PDL radio modem

Step 1

Position the radio where it is accessible for the operator to select a new radio channel ID.



Permanent mount

For a permanent mount, bolt the radio onto a bracket with a $^{5}/_{8}$" UNC screw.




Temporary mount

For a temporary mount (so it can be moved between vehicles), mount the radio on a magnet with a $^{5}/_{8}$" UNC stud.



Step 2

Connect the radio antenna cable adaptor to the radio.



Step 3

Connect the radio cable to the adaptor.



CHAPTER

6


Power Harness Installation

In this chapter:

- FmX integrated display components
- EZ-Guide 500 lightbar components
- Installing the power harness for the FmX integrated display
- Configuring the power bus options for the FmX integrated display
- Configuring the power bus options for the EZ-Guide 500 lightbar


This chapter describes how to install the power harness in the vehicle.

FmX integrated display components



Item	Description	Trimble Part No.
❶	FmX integrated display	93100-02
❷	FmX power cable	66694
❸	FmX power cable with relay and switch (power bus)	67259
❹	Basic power cable	67258
❺	FmX to NavController II cable with port replicator	65522
❻	2 pin DTM to 2 pin DT power adaptor	67095
❼	NavController II	55563-00
❽	External switch cable incl with kit	Part of P/N 67259
❾	External switch incl with kit	Part of P/N 67259
❿	Main NavController II cable	54601

EZ-Guide 500 lightbar components



Item	Description	Trimble Part No.
❶	*Ag*GPS EZ-Guide 500 lightbar	
❷	*Ag*GPS EZ-Guide 500 lightbar 19 pin port expansion cable	62069
❸	*Ag*GPS EZ-Guide 500 lightbar/CAN 90° 5 pin connector	62817
❹	*Ag*GPS EZ-Guide 500 lightbar port A to NavController II cable	62754
❺	Switch cable	Part of P/N 67259
❻	Switch	67095
❼	FmX power cable with relay and switch	67259
❽	FmX basic power cable	67258
❾	2 pin DTM to 2 pin 2 DT power adaptor	67095
❿	NavController II main cable	54601
⓫	NavController II	55563-00

Installing the power harness for the FmX integrated display

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information chapter.


Step 1

Connect the basic power cable to the vehicle battery and then route the cable into the cab.




Step 2

Locate and connect the 4-pin Deutsch DTP receptacle on the power bus to the 4-pin Deutsch DTP plug on the basic power cable.




Step 3

Remove the protective receptacle from the power bus.



Step 4

Locate and connect the 4-pin Deutsch DTP receptacle on the FmX integrated display power adaptor to the 4-pin Deutsch DTP plug on the power bus.



Step 5

Route the FmX integrated display power adaptor to the display mounting location and then connect it to the display.



Configuring the power bus options for the FmX integrated display


WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information chapter.

When you use the power bus cable, use one of the following configuration methods to turn on the Autopilot system:

- FmX integrated display power button is used to turn on the Autopilot system
- External switch is used to turn on the Autopilot system
- Ignition is used to turn on the Autopilot system

FmX integrated display power button is used to turn on the Autopilot system


Connect the 2 pin connectors labeled R2 and P2 on the power bus.



External switch is used to turn on the Autopilot system

Step 1

Connect the cable labeled R7 switch (included with the power bus) to connector labeled P2 on the power bus.



Step 2

Route the cable labeled R7 to a switch location.


Note – *To install the switch provided, drill a ¾" hole.*



Step 3

Connect the cable labeled R7 to the switch pins.

Note – *Polarity is not important.*



Installing the optional illuminated full or standard Euro switch

Step 1

Find an available knockout location on the vehicle console.

Note – *An alternative location is required for the switch provided.*




Step 2

Route the cable labeled R7 to the switch location and then connect the cable to the illuminated switch.

Connect the wire labelled S1 to pin 5 on the switch and then connect the wire labelled S2 to pin 4 on the switch.


Note – *Polarity is important.*



Step 3

Connect a separate wire to pin 3 on the switch using a spade connector. Route the wire and then connect it to the vehicle switched power.

Note – *This additional wire is required to allow the switch to illuminate.*




Ignition is used to turn on the Autopilot system

Note – *For more information on how to use the ignition sensing option, see the FmX Integrated Display User Guide.*


Step 1

Connect the 2-pin connectors labeled R2 and P2 on the power bus.



Step 2

Connect the cable labeled R8 Ignition (included with the power bus) to connector P3 Ignition on the power bus.




Step 3

Route the cable to the vehicles ignition.

Step 4

Connect the red ignition sense wire to the vehicle ignition using the spade or ring terminal provided.



Configuring the power bus options for the EZ-Guide 500 lightbar

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information chapter.

Note – *For the AgGPS EZ-Guide 500 lightbar cable installation instructions see,* *EZ-Guide 500 lightbar components, page 87*


Step 1

Locate and connect the basic power cable to the vehicle battery and then route the cable into the cab.



Step 2


Locate and connect the 4-pin Deutsch DTP receptacle on the power bus to the 4-pin Deutsch DTP plug on the basic power cable.



Step 3


Verify that the protective receptacle is installed on the power bus.

Note – *Damage to the system may result if the protective receptacle is not in place.*



Step 4

Connect the cable labeled R7 switch (included with the power bus) to the connector labeled P2 on the power bus.



Step 5

Route cable labeled R7 to a switch location.


Note – *To install the switch provided, drill a ¾" hole.*



Step 6

Connect cable labeled R7 to the switch pins

Note – *Polarity is not important.*



Installing the optional illuminated full or standard Euro switch

Step 1

Find an available knockout location on the vehicle console.

Note – *An alternative location is required for the switch provided.*




Step 2

Route the cable labeled R7 to the switch location and then connect the cable to the illuminated switch.

Connect the wire labelled S1 to pin 5 on the switch and then connect the wire labelled S2 to pin 4 on the switch.


Note – *Polarity is important.*



Step 3

Connect a separate wire to pin 3 on the switch using a spade connector. Route the wire and then connect it to the vehicles switched power.

Note – *This additional wire is required to allow the switch to illuminate.*



CHAPTER

7

Remote Engage Switch Installation

In this chapter:

- Remote engage switch components: Rocker switch
- Remote engage switch components: Foot switch
- Preparing the remote engage cable
- Using the remote engage switch

This chapter describes how to install the remote engage switch.


Remote engage switch components: Rocker switch



Item	Description
❶	DTM receptacle
❷	Remote engage rocker switch

Note – *This is a Full or Standard Euro switch, depending on the kit ordered.*

Remote engage switch components: Foot switch




Item	Description
❶	DTM receptacle
❷	Remote engage foot switch

Preparing the remote engage cable


Step 1

Locate the green 12-pin Deutsch receptacle on the P-5 leg of the main controller harness. For more information, see Chapter 8, Controller connections.



Step 2


Remove the wedge from the connector.



Step 3


Rocker switch only

Remove the plugs from cavity 2 and cavity 7.



Foot Switch Only


Remove the plugs from cavity 2, cavity 7, and cavity 11.



Step 4


Rocker switch only

Insert the DTM pins into cavity 2 and cavity 7, according to the labels on the wires.




Foot switch only

Insert the DTM pins into cavity 2, cavity 7, and cavity 11, according to the labels on the wires.



Step 5

Pull on the wires to seat them in place and then replace the wedge in the connector.



Step 6

Rocker switch only

Run the spade ends of the cable to a knockout location in the operator console.



Foot switch only


Run the cable to a clear location on the floor board. Use double-sided tape to secure the pedal. Route the cable under the floor mat.



Step 7

Rocker Switch Only

Connect the wires to the switch. Match the print on the switch body with the labels on the wires.



Step 8

Rocker Switch Only

Place the switch in the console.



Using the remote engage switch

Step 1

Hold the switch down for at least 0.5 seconds.

Note – *Holding the switch for less than 0.5 seconds will not engage the system.*

Step 2

Release the switch between 0.5 and 4.0 seconds. When you release the switch, the vehicle will engage.

CHAPTER

8

Controller Installation

In this chapter:

- Installing the controller
- Controller connections
- Connecting the cables to the controller

This chapter describes how to install the controller unit.

Installing the controller

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information chapter.

Step 1

Trimble recommends that the controller is mounted on the rear cab wall, with the cables to the right side of the machine.



Step 2

Position the mount plate in the desired location and then mark four of the mount hole locations on the back wall.

Note – *Ensure that the plate is level when marking.*



Step 3

Drill the four holes as marked with a $^{3}/_{8}$" diameter bit.

Note – *To ensure proper alignment it is advised that after drilling the first hole, bolt the plate in place with a single bolt and match drill the remaining holes.*

CAUTION – Ensure that the drill bit does not puncture the spray reservoir tank. A short bit, or a drill stop is recommended.



Step 4

Use the supplied bolts and washers to attach four hex standoffs to the cab wall. Ensure that the standoffs pass through the interior padding and seat against the wall itself.



Step 5

Attach the mounting plate to the standoffs and tighten all fasteners securely.




Step 6

Use the supplied screws to attach the controller to the mounting plate.



Controller connections



Item	Description
1	NavController II controller
P2	Power connector
P3	GPS connector
P4	Display connector
P5	Vehicle sensors connector
P6	Steering sensor connector
P7	Manual override connector
P8	Hydraulic valve connector


Item	Description
P9	Sonalert connector
P12	Lightbar/spare connector
P13	Spare sensors connector
14	Status indicator
15	Laptop connector
16	Main harness
17	Auxiliary harness

Connecting the cables to the controller

Step 1


Connect the power cable connection to P-2, which is labeled "Power". P-2 is located on the main wiring harness.

Note – *The power connection supplies power through the controller to all connected devices, including GPS and displays.*



Step 2


Connect the GPS cable connection to P-3, which is labeled "GPS". P-3 is located on the main wiring harness.



Step 3


Connect the primary display cable connection to P-4, which is labeled "Display". P-4 is located on the main wiring harness.

Note – *Do not connect the cable to the connector labeled "Spare" on the auxiliary harness.*



Step 4


Connect the steering sensor cable connection to P-6, which is labeled "Steering Sensor". P-6 is located on the main wiring harness.



Step 5


Connect the manual override cable connection to P-7, which is labeled "Manual Override". P-7 is located on the main wiring harness.

Note – *When you install the remote engage harness, add the pins to the existing connector.*



Step 6


Connect the hydraulic steering valve cable connection to P-8, which is labeled "Hydraulic Valve". P-8 is located on the main wiring harness.



Step 7


When using a lightbar as a secondary display to an *Ag*GPS 170 field computer, connect the lightbar cable connection to P-12, which is labeled "Lightbar/Spare". P-12 is located on the auxiliary wiring harness.

Note – *If an AgGPS 50 or AgGPS 150 lightbar is connected to P-12, it will act as a lightbar only.*




Step 8

Connect the Sonalert P-9 to the 2-pin Delphi connector on the main wiring harness. Route the cable so the Sonalert warning device is in a position that is audible to the operator.



Step 9

Route the LED and laptop lead, which is located on the auxiliary wiring harness, to a location that allows the operator to determine the controller status. See controller LED status for status determination. Six flashes per second indicates a correctly functioning controller.



Step 10

Use the provided sleeving to secure the harness cables with tie wraps. Cover and route the cable bundle to avoid damage to connectors and strain on wire connections.

CHAPTER

9

Final Machine Check

In this chapter:

- Performing the final machine check

This chapter describes how to perform a final check of the vehicle.

Performing the final machine check

WARNING – To avoid potentially serious personal injury or illness, and to prevent damage to equipment, make sure that you read and understand the Safety Information chapter.

Step 1

Connect the battery.

Step 2

Start the machine and check for hydraulic leaks. Correct as needed.

Step 3

Connect and run the *Ag*GPS Autopilot Toolbox II software for system setup and calibration. For more information, refer to the *AgGPS Autopilot Toolbox II Software User Guide*.

Step 4

Open the *Diagnostic* page of the *Ag*GPS Autopilot Toolbox II software and ensure that all signals from the hydraulics and sensors are active.