



ChDp Ventures
221290 Twp Rd 372 PO Box 62
Muenster SK S0K 2Y0
+1 (306) 900-2072
sales@chdp.ventures

KarTech Remote Teach (Learn) Instructions

After servicing of KarTech remotes, it is often required to pair the remote with the transmitter on the machine again. To do this, follow these instructions:

- 1. Turn both transmitter and receiver off**
- 2. To get the transmitter into TEACH ID mode, press and hold the POWER button for 10 seconds.**
- 3. Turn on the receiver.**
- 4. Teach complete**